


## INSTRUCTION MANUAL

Light Curtain Type 4 / Light Curtain for Press and Cutting machine in Korea

**SF4B-□-03<V2>**



(MEMO)

Thank you for purchasing Panasonic Electric Works SUNX's Light Curtain, **SF4B-□-03<V2>**.  
Please read this instruction manual carefully and thoroughly for the correct and optimum use of this device.  
Kindly keep this manual in a convenient place for quick reference.

This device is a light curtain for protecting a person from dangerous parts of a machine which can cause injury or accident.

This manual has been written for the following personnel who have undergone suitable training and have knowledge of light curtains, as well as, safety systems and standards.

- who are responsible for the introduction of this device
- who design the system using this device
- who install and connect this device
- who manage and operate a plant using this device

#### Notes

- 1) All the contents of this instruction manual are the copyright of the publishers, and may not be reproduced (even extracts) in any form by any electronic or mechanical means (including photocopying, recording, or information storage and retrieval) without permission in writing from the publisher.
- 2) The contents of this instruction manual may be changed without prior notice for further improvement of the device.
- 3) Though we have carefully drawn up the contents of this instruction manual, if there are any aspects that are not clear, or any error that you may notice, please contact our local Panasonic Electric Works SUNX office of the nearest distributor.
- 4) English and Japanese are original instructions.

# Contents



<b>Chapter 1 Introduction</b>	<b>5</b>
1-1 Attention Marks	5
1-2 Safety Precautions	5
1-3 Applicable Standards / Regulations	8
1-4 Confirmation of Packed Contents	9
<b>Chapter 2 Before Using This Device</b>	<b>10</b>
2-1 Features	10
2-2 Part Description	10
2-3 Protection Area	13
2-3-1 Sensing Area	13
2-3-2 Safety Distance	14
2-3-3 Influence of Reflective Surfaces	18
2-3-4 Device Placement	19
2-4 Mounting	20
2-4-1 Mounting of the Mounting Bracket	20
2-4-2 Mounting of the Bottom Cap Cable (Optional)	27
2-4-3 Extension and Dismantling of Sensor (Series Connection)	28
2-5 Wiring	30
2-5-1 Power Supply Unit	30
2-5-2 I/O Circuit Diagrams and Output Waveform	31
2-5-3 Wiring · Connecting Procedure and Connector Pin Arrangement	33
2-5-4 Basic Wiring	35
2-5-5 Wiring for Manual Reset (Interlock is Valid)	37
2-5-6 Series Connection	39
2-5-7 Wiring for Auto-reset (Interlock is Invalid)	41
2-5-8 Wiring Configuration for Invalid External Device Monitor Function	43
2-6 Adjustment	45
2-6-1 Beam-axis Alignment	45
2-6-2 Operation Test	47
2-6-3 Operation	48
<b>Chapter 3 Functions</b>	<b>54</b>
3-1 Self-diagnosis Function	54
3-2 Interlock Function	54
3-3 Emission Halt Function	55
3-4 Interference Prevention Function	55
3-5 Auxiliary Output (Non-safety Output)	56
3-6 External Device Monitor Function	56
<b>Chapter 4 Maintenance</b>	<b>58</b>
4-1 Daily Inspection	58
4-2 Periodic Inspection (Every Six Months)	59
4-3 Inspection after Maintenance	59


<b>Chapter 5 Troubleshooting .....</b>	<b>60</b>
5-1 Troubleshooting of Emitter.....	60
5-2 Troubleshooting of Receiver .....	62
 <b>Chapter 6 Specifications / Dimensions .....</b>	 <b>64</b>
6-1 Specifications.....	64
6-2 Options .....	67
6-3 Dimensions .....	72
6-3-1 When Using M8 Rear Mounting Bracket ( <b>MS-SFB-7-T</b> ) .....	72
6-3-2 When Using M8 Side Mounting Bracket ( <b>MS-SFB-8-T</b> ) .....	73
6-3-3 Rear Mounting with Dead Zoneless Mounting Bracket ( <b>MS-SFB-3</b> ) .....	74
6-3-4 Side Mounting with Dead Zoneless Mounting Bracket ( <b>MS-SFB-3</b> ) .....	75
6-3-5 Mounting Brackets .....	76
 <b>Chapter 7 Others .....</b>	 <b>80</b>
7-1 Glossary.....	80
7-2 CE Marking Declaration of Conformity .....	82


# Chapter 1 Introduction

---

## 1-1 Attention Marks

This instruction manual employs the following attentions marks ,  depending on the degree of the danger to call operator's attention to each particular action. Read the following explanation of these marks thoroughly and observe these notices without fail.

 **WARNING** If you ignore the advice with this mark, death or serious injury could result.

 **CAUTION** If you ignore the advice with this mark, injury or material damage could result.

**<Reference>** It gives useful information for better use of this device.

## 1-2 Safety Precautions

- Use this device as per its specifications. Do not modify this device since its functions and capabilities may not be maintained and it may malfunction.
- This device has been developed / produced for industrial use only.
- This device is suitable for indoor use only.
- Use of this device under the following conditions or environments is not presupposed. Please consult us if there is no other choice but to use this device in such an environment.
  - 1) Operating this device under conditions or environments not described in this manual.
  - 2) Using this device in the following fields: nuclear power control, railroad, aircraft, automobiles, combustion facilities, medical systems, aerospace development, etc.
- When this device is to be used for enforcing protection of a person from any danger occurring around an operating machine, the user should satisfy the regulations established by national or regional security committees (Occupational Safety and Health Administration: OSHA, the European Standardization Committee, etc.). Contact the relative organization(s) for details.
- In case of installing this device to a particular machine, follow the safety regulations in regard to appropriate usage, mounting (installation), operation and maintenance. The users including the installation operator are responsible for the introduction of this device.
- Use this device by installing suitable protection equipment as a countermeasure for failure, damage, or malfunction of this device.
- Before using this device, check whether the device performs properly with the functions and capabilities as per the design specifications.
- In case of disposal, dispose this device as an industrial waste.

## **WARNING**

### ◆ **Machine designer, installer, employer and operator**

- The machine designer, installer, employer and operator are solely responsible to ensure that all applicable legal requirements relating to the installation and the use in any application are satisfied and all instructions for installation and maintenance contained in the instruction manual are followed.
- Whether this device functions as intended to and systems including this device comply with safety regulations depends on the appropriateness of the application, installation, maintenance and operation. The machine designer, installer, employer and operator are solely responsible for these items.

### ◆ **Engineer**

- The engineer would be a person who is appropriately educated, has widespread knowledge and experience, and can solve various problems which may arise during work, such as a machine designer, or a person in charge of installation or operation etc.

### ◆ **Operator**

- The operator should read this instruction manual thoroughly, understand its contents, and perform operations following the procedures described in this manual for the correct operation of this device.
- In case this device does not perform properly, the operator should report this to the person in charge and stop the machine operation immediately. The machine must not be operated until correct performance of this device has been confirmed.

### ◆ **Environment**

- Do not use a mobile phone or a radio phone near this device.
- If there exists a reflective surface in the place where this device is to be installed, make sure to install this device so that reflected light from the reflective surface does not enter into the receiver, or take countermeasures such as painting, masking, roughening, or changing the material of the reflective surface, etc. Failure to do so may cause the device not to detect, resulting in death or serious injury.
- Do not install this device in the following environments.
  - 1) Areas exposed to intense interference (extraneous) light such as high-frequency fluorescent lamp (inverter type), rapid starter fluorescent lamp, stroboscopic lights or direct sunlight.
  - 2) Areas with high humidity where condensation is likely to occur
  - 3) Areas exposed to corrosive or explosive gases
  - 4) Areas exposed to vibration or shock of levels higher than that specified
  - 5) Areas exposed to contact with water
  - 6) Areas exposed to too much steam or dust

### ◆ **Installation**

- Always keep the correctly calculated safety distance between this device and the dangerous parts of the machine.
- Install extra protection structure around the machine so that the operator must pass through the sensing area of this device to reach the dangerous parts of the machine.
- Install this device such that some part of the operator's body always remains in the sensing area when operator is done with the dangerous parts of the machine.
- Do not install this device at a location where it can be affected by wall reflection.
- When installing multiple sets of this device, connect the sets and, if necessary, install some barriers such that mutual interference does not occur. For details, refer to "**2-3-4 Device Placement**" and "**3-4 Interference Prevention Function**."
- Do not use this device in a reflective configuration.
- The corresponding emitter and receiver must have the same serial No. and be correctly oriented.

## **WARNING**

### ◆ **Machine in which this device is installed**

- When this device is used in the “PSDI Mode,” an appropriate control circuit must be configured between this device and the machinery. For details, be sure to refer to the standards or regulations applicable in each region or country.
- This device can be used as safety equipment for a press machine in Korea. In Japan, do not use this device as safety equipment for a press machine.
- Do not install this device with a machine whose operation cannot be stopped immediately in the middle of an operation cycle by an emergency stop equipment.
- This device starts the performance after 2 seconds from the power ON. Have the control system started to function with this timing.

### ◆ **Wiring**

- Be sure to carry out the wiring in the power supply OFF condition.
- All electrical wiring should conform to the regional electrical regulations and laws. The wiring should be done by engineer(s) having the special electrical knowledge.
- Do not run the wires together with high-voltage lines or power lines or put them in the same raceway. This can cause malfunction due to induction.
- In case of extending the cable of the emitter or the receiver, each can be extended up to 50m by using the exclusive cable. Furthermore, if the cable is extended in the state that the device is in series connection is used, the total extendable length of the cable depends on the number of the devices in series connection. For details, refer to “**2-5-3 Wiring · Connecting Procedure and Connector Pin Arrangement.**”
- Do not control the device only at one control output (OSSD 1 / 2).
- In order that the output is not turned to ON due to earth fault of the control output (OSSD 1 / 2) wires, be sure to ground to 0V side (PNP output) / +24V side (NPN output).

### ◆ **Maintenance**

- When replacement parts are required, always use only genuine supplied replacement parts. If substitute parts from another manufacturer are used, the device may not come to detect, result in death or serious injury.
- The periodical inspection of this device must be performed by an engineer having the special knowledge.
- After maintenance or adjustment, and before starting operation, test this device following the procedure specified in “**Chapter 4 Maintenance.**”
- Clean this device with a clean cloth. Do not use any volatile chemicals.

### ◆ **Others**

- Never modify this device. Modification may cause the device not to detect, resulting in death or serious injury.
- Do not use this device to detect objects flying over the sensing area.
- Do not use this device to detect transparent objects, translucent objects or objects smaller than the specified minimum sensing objects.



## 1-3 Applicable Standards / Regulations

This device complies with the following standards / regulations.

### <EU Directives>

EU Machinery Directive 2006/42/EC

EMC Directive 2004/108/EC

### <European Standards>

EN 61496-1 (Type 4), EN 55011, EN ISO 13849-1: 2008 (Category 4, PLe)

### <International Standards>

IEC 61496-1/2 (Type 4), ISO 13849-1: 2006 (Category 4, PLe), IEC 61508-1 to 7 (SIL3)

### <Japanese Industrial Standards (JIS)>

JIS B 9704-1/2 (Type 4), JIS B 9705-1 (Category 4), JIS C 0508 (SIL3)

### <Standards in US / Canada>

ANSI/UL 61496-1/2 (Type 4), ANSI/UL 508, UL 1998 (Class 2)

CAN/CSA C22.2 No.14, CAN/CSA C22.2 No.0.8

### <Regulations in US>

OSHA 1910.212, OSHA 1910.217(C), ANSI B11.1 to B11.19, ANSI/RIA 15.06

Regarding EU Machinery Directive, a Notified Body, TUV SUD, has certified with the type examination certificate.

With regard to the standards in US / Canada, a NRTL, UL (Underwriters Laboratories Inc.) has certified for C-UL US Listing Mark.

### <Regulations in Korea>

A safety certificate of protection equipment for press and cutting machine based on Korea Industrial safety and health Act 34th and the enforcement regulation 58th 4 has been certificate.

### <Reference>

The conformity to JIS, OSHA and ANSI for this device has been evaluated by ourselves.

The C-UL US Listing Mark «®» indicates compliance with both Canadian and US requirements.

This device conforms to the EMC Directive and the Machinery Directive. The «CE» mark on the main body indicates that this device conforms to the EMC Directive. The «K» mark attached on this device shows that this device has passed Korean type examination.

### WARNING

- In Japan, never use this device as a safety equipment for any press machine or shearing machine.
- When this device is used in a place other than the places shown above, be sure to confirm the standards or regulations applicable in each region or country before use

## 1-4 Confirmation of Packed Contents

- Sensor: Emitter, Receiver 1 pc. each
  - Test Rod 1 pc.
    - SF4B-F□-03<V2>: SF4B-TR14** (ø14 × 220mm)
    - SF4B-H□-03<V2>: SF4B-TR25** (ø25 × 220mm)
  - Intermediate Supporting Bracket (**MS-SFB-2**) 0 to 3 sets
- Note: The intermediate support bracket (**MS-SFB-2**) is enclosed with the following devices. The quantity differs depending on the device as shown below:
- 1 set: **SF4B-F□-03<V2>** ... 79 to 111 beam channels
    - SF4B-H□-03<V2>** ... 40 to 56 beam channels
  - 2 sets: **SF4B-F127-03<V2>**, **SF4B-H□-03<V2>** ... 64 to 80 beam channels
  - 3 sets: **SF4B-H□-03<V2>** ... 88 to 96 beam channels
- Instruction Manual (this manual) 1 pc.


## Chapter 2 Before Using This Device

### 2-1 Features

This device is the light curtain with the following features.

- No special controller is required.
- The control output (OSSD 1 / 2) is PNP / NPN output switching type.
- Beam-axis alignment indicators which make beam-axis alignment easy are incorporated.
- Refer to “6-2 Options” for details of options.

### 2-2 Part Description



**<Emitter>**

It emits light to the receiver facing it. Furthermore, the status of the emitter and the receiver is indicated on its display section.

**<Receiver>**

It receives light from the emitter facing it. Simultaneously, it turns ON the control output (OSSD 1 / 2) when the all beam channels receive light from emitter, and it turns OFF the control output (OSSD 1 / 2) when one or more beam channels are blocked light.

**<Beam channel>**

The light emitting elements of the emitter and the light receiving elements of the receiver are placed at the following intervals, 10mm (SF4B-F□-03<V2>) and 20mm (SF4B-H□-03<V2>).

**<M8 rear mounting bracket (optional)>**

This bracket allows the emitter / receiver to be mounted at the rear with one M8 hexagon-socket head bolt. Horizontal angle can be adjusted.

**<M8 side mounting bracket (optional)>**

This bracket allows the emitter / receiver to be mounted at the side with one M8 hexagon-socket head bolt. Horizontal angle can be adjusted.

**<M5 / M8 360°-rotatable mounting bracket (optional)>**

This bracket is to be used for mounting the emitter / receiver. It is installed using two M5 hexagon-socket head bolts or one M8 hexagon-socket head bolt. 360° horizontal angle rotation can be done.

**<M8 360°-rotatable mounting bracket (optional)>**

This bracket is to be used for mounting the emitter / receiver. It is installed using one M8 hexagon-socket head bolt. 360° horizontal angle rotation can be done.

**<M5 pitch adapter bracket (optional)>**

This is used as the mounting bracket when changing over a previous light curtain with a sensing height of 200 to 750mm to this device. It is installed using two M5 hexagon-socket head bolts. 360° horizontal angle rotation can be done.

**<M8 pitch adapter bracket (optional)>**

This is used as the mounting bracket when changing over a previous light curtain with a sensing height of 200 to 750mm to this device. It is installed using one M8 hexagon-socket head bolt. 360° horizontal angle rotation can be done.

**<Dead zoneless mounting bracket (optional)>**


This bracket is to be used for mounting the emitter / receiver. This is useful for mounting the device to the limited mounting space.

**<Intermediate supporting bracket>**


This bracket is to be used for mounting the device having 79 beam channels or more for SF4B-F□-03<V2>, 40 beam channels or more for SF4B-H□-03<V2>.

## <Display section>


### Emitter



Beam-axis alignment indicator [RECEPTION]



### Receiver



Description	Function
Beam-axis alignment indicator (Red / Green) [RECEPTION]	A When device top receives light: lights up in red When device top end receives light: blinks in red When control output (OSSD 1 / 2) is ON: lights up in green
	B When device upper middle receives light: lights up in red When control output (OSSD 1 / 2) is ON: lights up in green
	C When device lower middle receives light: lights up in red When control output (OSSD 1 / 2) is ON: lights up in green
	D When device bottom receives light: lights up in red When device bottom end receives light: blinks in red When control output (OSSD 1 / 2) is ON: lights up in green
Operator indicator (Red / Green) [OSSD] (Note 1)	Lights up while device operation is as follows [sequential operation control output (OSSD 1 / 2)] When control output (OSSD 1 / 2) is OFF: lights up in red When control output (OSSD 1 / 2) is ON: lights up in green
Incident light intensity indicator (Orange / Green) [STB.]	When sufficient light is received (Incident light: 130% or more) (Note 2): lights up in green When stable light is received (Incident light: 115 to 130%) (Note 2): OFF When unstable light is received (Incident light: 100 to 115%) (Note 2): lights up in orange When light is blocked: OFF (Note 3)
Fault indicator (Yellow) [FAULT]	When fault occurs in the device: lights up or blinks
Digital error indicator (Red)	When device is lockout, error contents are indicated.
PNP indicator (Orange) [PNP]	When PNP output is set: lights up
NPN indicator (Orange) [NPN]	When NPN output is set: lights up
Emission intensity control indicator (Orange) [CTRL]	When light is emitted under short mode: lights up
	When light is emitted under normal mode: OFF
Emission halt indicator (Orange) [HALT]	When light emission is halt: lights up When light is emitted: OFF

Description	Function
Beam-axis alignment indicator (Red / Green) [RECEPTION]	A When device top receives light: lights up in red When device top end receives light: blinks in red When control output (OSSD 1 / 2) is ON: lights up in green
	B When device upper middle receives light: lights up in red When control output (OSSD 1 / 2) is ON: light up in green
	C When device lower middle receives light: lights up in red When control output (OSSD 1 / 2) is ON: lights up in green
	D When device bottom receives light: lights up in red When device bottom end receives light: blinks in red When control output (OSSD 1 / 2) is ON: lights up in green
OSSD indicator (Red / Green) [OSSD]	When control output (OSSD 1 / 2) is OFF: lights up in red When control output (OSSD 1 / 2) is ON: lights up in green
Incident light intensity indicator (Orange / Green) [STB.]	When sufficient light is received (Incident light: 130% or more) (Note 2): lights up in green When stable light is received (Incident light: 115 to 130%) (Note 2): OFF When unstable light is received (Incident light: 100 to 115%) (Note 2): lights up in orange When light is blocked: OFF (Note 3)
Fault indicator (Yellow) [FAULT]	When fault occurs in the device: light up or blinks
Digital error indicator (Red)	When device is lockout, error contents are indicated.
PNP indicator (Orange) [PNP]	When PNP output is set: light up
NPN indicator (Orange) [NPN]	When NPN output is set: lights up
Function setting indicator (orange) [FUNCTION]	Always OFF
Interlock indicator (Yellow) [INTERLOCK]	When device is interlocked: lights up Other cases: OFF

- Notes: 1) Since the color of the operation indicator changes according to ON / OFF status of the control output (OSSD 1 / 2), the operation indicator is marked as "OSSD" on the device.
- 2) The threshold where the control output (OSSD 1 / 2) changes from OFF to ON is applied as "100% incident light intensity".
- 3) "When light is blocked" refers to the status that there exists any object blocking light in the sensing area.
- 4) The description given in [ ] is marked on the device.


## 2-3 Protection Area

### 2-3-1 Sensing Area


#### **WARNING**

- Be sure to install protection structure around the machine so that the operator must pass through the sensing area of this device to reach the dangerous parts of the machine. Furthermore, ensure that some part of the operator's body always remains in the sensing area when operation is done with the dangerous parts of the machine. Failure to do so can result in death or serious injury.
- Do not use any reflection type or recursive reflection type arrangement.
- Furthermore, facing several receivers towards one emitter, or vice versa, could produce a non-sensing area or cause mutual interference, which may result in death or serious injury.


The sensing area is the zone formed by the sensing height of the device and the sensing range between the emitter and the receiver. The sensing height is determined by the number of beam channels. Furthermore, the sensing range can be 0.3 to 9m for **SF4B-H□-03<V2>** (12 to 64 beam channels), 0.3 to 7m for **SF4B-F□-03<V2>** and **SF4B-H□-03<V2>** (72 to 96 beam channels). Take care that the sensing range becomes short after mounting either protection cover (**FC-SFBH-□**) (optional). Take care that if the sensing range is under 0.3m, malfunction may occur due to the optical structure.



#### <Example of Correct Installation>



#### <Example of Incorrect Installation>




## 2-3-2 Safety Distance

### **WARNING**

Calculate the safety distance correctly, and always maintain the distance which is equal to or greater than the safety distance, between the sensing area of this device and the dangerous parts of the machine. If the safety distance is miscalculated or if sufficient distance is not maintained, the machine will not stop quickly before reaching to the dangerous parts, which can result in death or serious injury.

The safety distance is the minimum distance that must be maintained between the device and the dangerous parts of the machine so that the machine can be stopped before a human body or an object can reach the dangerous parts.

The safety distance is calculated based on the equation described in the next page when a person moves perpendicular (normal intrusion) to the sensing area of the device.



### **WARNING**

Before designing the system, refer to the relevant standards of the region where this device is to be used, and then install this device.

Furthermore, the equation described in the next pages is to be used only in case the intrusion direction is perpendicular to the sensing area. In case the intrusion direction is not perpendicular to the sensing area, be sure to refer to the relevant standard (regional standard, specification of the machine, etc.) for details of the calculation.

### **WARNING**

The max. response time of the machine is from the point that the machine receives the halt signal from this device to the point that the dangerous parts of the machine stops. The max. response time of the machine should be timed with the machine to be actually used.

**[For use in Europe (EU) (as EN 999)] (Also applicable to ISO 13855)**

(For intrusion direction perpendicular to the sensing area)

**<In case that the minimum sensing object is ø40mm or less>**

• Equation 1             $S = K \times T + C$

S : Safety distance (mm)

Minimum required distance between the sensing area surface and the dangerous parts of the machine

K : Intrusion velocity of operator's body or object (mm/sec.)

Taken as 2,000 (mm/sec.) for calculation

T : Response time of total equipment (sec.)

$T = T_m + TSF4B$

$T_m$ : Maximum halting time of machine (sec.)

TSF4B: Response time of this device (sec.)

C : Additional distance calculated from the size of the minimum sensing object of the device (mm)

However, the value of C cannot be under 0.

$C = 8 \times (d - 14)$

d: Minimum sensing object diameter (mm)

**<Reference>**

- For calculating the safety distance S, there are the following five cases.  
First calculate by substituting the value  $K = 2,000$  (mm/sec.) in the equation above. Then, classify the obtained value of S into three cases, 1)  $S < 100$ , 2)  $100 \leq S \leq 500$ , and 3)  $S > 500$ .  
For Case 3)  $S > 500$ , recalculate by substituting the value  $K = 1,600$  (mm/sec.). After that, classify the calculation result into two cases, 4)  $S \leq 500$  and 5)  $S > 500$ . For details, refer to "Calculation Example 1 For use in Europe."
- When this device is used in the "PSDI Mode," an appropriate safety distance S must be calculated. For details, be sure to refer to the standards or regulations applicable in each region or country.



### <Calculation Example>

- Calculation Example 1: For use in Europe  
(OFF response time: 14ms or less, minimum sensing object diameter: 14mm)

First, calculate with  $K = 2,000$ .

$$\begin{aligned} S &= K \times T + C \\ &= K \times (T_m + T_{SF4B}) + 8 \times (d - 14) \\ &= 2,000 \times (T_m + 0.014) + 8 \times (14 - 14) \\ &= 2,000 \times T_m + 2,000 \times 0.014 \\ &= 2,000 \times T_m + 28 \end{aligned}$$

If the result is:

- 1) In case  $S < 100$  (mm)  
Safety distance  $S$  is taken as 100 (mm)
- 2) In case  $100 \leq S \leq 500$  (mm)  
Safety distance  $S$  is taken as  $2,000 \times T_m + 28$  (mm)
- 3) In case  $S > 500$  (mm)  
$$\begin{aligned} S &= K' \times (T_m + T_{SF4B}) + 8 \times (d - 14) \\ &= 1,600 \times (T_m + 0.014) + 8 \times (14 - 14) \\ &= 1,600 \times T_m + 1,600 \times 0.014 \\ &= 1,600 \times T_m + 22.4 \end{aligned}$$

then, calculate again.

If the result is:

- 4) In case  $S \leq 500$  (mm)  
Safety distance  $S$  is taken as 500 (mm)
- 5) In case  $S > 500$  (mm)  
Safety distance  $S$  is taken as  $1,600 \times T_m + 22.4$  (mm)

In case this device is installed in a system with a maximum halting time of 0.1 (sec.)

$$\begin{aligned} S &= 2,000 \times T_m + 28 \\ &= 2,000 \times 0.1 + 28 \\ &= 228 \end{aligned}$$

Since this value matches with Case 2) above,  $S$  is 228 (mm).

In case this device is installed in a system with a maximum halting time of 0.4 (sec.)

$$\begin{aligned} S &= 2,000 \times T_m + 28 \\ &= 2,000 \times 0.4 + 28 \\ &= 828 \end{aligned}$$

Since this value matches with Case 3) above,

$$\begin{aligned} S &= 1,600 \times T_m + 22.4 \\ &= 1,600 \times 0.4 + 22.4 \\ &= 662.4 \end{aligned}$$

Since this value matches with Case 5) above,  $S$  is 662.4 (mm).

**[For use in the United States of America (as per ANSI B11.19)]**

- Equation 2  $D_s = K \times (T_s + T_c + T_{SF4B} + T_{bm}) + D_{pf}$

- D<sub>s</sub>** : Safety distance (mm)  
Minimum required distance between the sensing area surface and the dangerous parts of the machine
- K** : Intrusion speed {Recommended value in OSHA is 63 (inch/sec.) [≈ 1,600 (mm/sec.)] }  
ANSI B11.19 does not define the intrusion speed “K”. When determining K, consider possible factors including physical ability of operators.
- T<sub>s</sub>** : Halting time calculated from the operation time of the control element (air valve, etc.) (sec.)
- T<sub>c</sub>** : Maximum response time of the control circuit required for functioning the brake (sec.)
- T<sub>SF4B</sub>** : Response time of this device (sec.)
- T<sub>bm</sub>** : Additional halting time tolerance for the brake monitor (sec.)  
The following equation holds when the machine is equipped with a brake monitor.  
 $T_{bm} = T_a - (T_s + T_c)$   
**T<sub>a</sub>**: Setting time of brake monitor (sec.)  
When the machine is not equipped with a brake monitor, it is recommended that 20% or more of (T<sub>s</sub> + T<sub>c</sub>) is taken as additional halting time.
- D<sub>pf</sub>** : Additional distance calculated from the size of the minimum sensing object of the device (mm)  
**SF4B-F□<V2>** D<sub>pf</sub> = 23.8mm  
**SF4B-H□<V2>** D<sub>pf</sub> = 61.2mm  

$$\left[ \begin{array}{l} D_{pf} = 3.4 \times (d - 0.276) \text{ (inch)} \\ \approx 3.4 \times (d - 7) \text{ (mm)} \\ d: \text{Minimum sensing object diameter } 0.552 \text{ (inch)} \approx 14 \text{ (mm)} \text{ **SF4B-F□-03<V2>**} \\ \text{Minimum sensing object diameter } 0.985 \text{ (inch)} \approx 25 \text{ (mm)} \text{ **SF4B-H□-03<V2>**} \end{array} \right]$$

**<Reference>**

Since the calculation above is performed by taking 1 (inch) = 25.4 (mm), there is a slight difference between the representation in (mm) and that in (inch). Refer to the relevant standard for the details.

**<Calculation Example>**

- Calculation Example 2 For use in the United States of America

[OFF response time: 14ms or less, minimum sensing object diameter: 0.552 (inch) ≈ 14 (mm)]

$$\begin{aligned} D_s &= K \times (T_s + T_c + T_{SF4B} + T_{bm}) + D_{pf} \\ &= 63 \times (T_a + 0.014) + 3.4 \times (d - 0.276) \text{ (inch)} \\ &= 63 \times (T_a + 0.014) + 3.4 \times (0.552 - 0.276) \\ &= 63 \times T_a + 63 \times 0.014 + 3.4 \times 0.276 \\ &= 63 \times T_a + 1.8204 \\ &\approx 63 \times T_a + 1.82 \text{ (inch)} \end{aligned}$$

In case this device is installed in a system with a maximum halting time 0.1 (sec.)

$$\begin{aligned} D_s &= 63 \times T_a + 1.82 \\ &= 63 \times 0.1 + 1.82 \\ &= 8.12 \text{ (inch)} \\ &\approx 206.248 \text{ (mm)} \end{aligned}$$

Hence, as per the calculations D<sub>s</sub> is 206.2 (mm).

**<Reference>**


Since the calculation above is performed by taking 1 (inch) = 25.4 (mm), there is a slight difference between the representation in (mm) and that in (inch). Refer to the relevant standard for the details.

## 2-3-3 Influence of Reflective Surfaces

### **WARNING**

If there exists a reflective surface in the place where this device is to be installed, make sure to install this device so that reflected light from the reflective surface does not enter into the receiver, or take countermeasures such as painting, masking, roughening, or changing the material of the reflective surface, etc. Failure to do so may cause the device not to detect, resulting in death or serious injury.


Install this device at a distance of at least A (m) (given below) away from reflective surfaces such as metal walls, floors, ceilings, workpieces, covers, panels or glass surfaces.



Distance between emitter and receiver (Sensing range L)	Allowable installation distance A
0.3 to 3m	0.16m
3 to 9m (Note 1)	$L/2 \times \tan 2\theta = L/2 \times 0.105 \text{ (m)} (\theta = 3^\circ)$

- Notes: 1) The sensing range L is applicable to **SF4B-H□-03<V2>** (12 to 64 beam channels). For **SF4B-F□-03<V2>** and **SF4B-H□-03<V2>** (72 to 96 beam channels), the distance between emitter and receiver is 3 to 7m.
- 2) The effective aperture angle for this device is  $\pm 2.5^\circ$  or less (when  $L > 3\text{m}$ ) as required by IEC 61496-2, ANSI/UL 61496-2. However, install this device away from reflective surfaces considering an effective aperture angle of  $\pm 3^\circ$  to take care of beam misalignment, etc. during installation.

### Allowable Distance from This Device to Reflective Surface




## 2-3-4 Device Placement

This is the configuration when two or more sets of emitter and receiver facing each other are placed without series connection between them. It is used for the case that there is a problem in wiring or for system evaluation in case of addition of equipment. Perform an operation test by referring to “2-6-2 Operation Test.”

### WARNING

- Refer to the examples of device placement given below and understand them thoroughly before installing the devices. Improper sensor placement could cause device malfunction, which can result in death or serious injury.
- If this device is used in multiple sets, arrange them to avoid mutual interference. If mutual interference occurs, it can result in death or serious injury.

### <Example of device placement>



### <Reference>

The above figures are just examples of device placement. If there are any questions or problems, please contact our office.

## 2-4 Mounting

### 2-4-1 Mounting of the Mounting Bracket

#### ⚠ CAUTION

- For selecting the appropriate mounting bracket matched to the installation environment, the mounting bracket is not incorporated in this device. Please purchase the optional mounting bracket to fit on the mounting environment.
- Do not apply the load such as forced bending to the cable of this device. Applying improper load could cause the wire breakage.
- The minimum bending radius of the cable is R6mm. Mount the device considering the cable bending radius.

#### ⚠ CAUTION

In case mounting the mounting bracket after mounting the bottom cap cable and the series connection cable, be sure drawing the cable to other side of the hexagon-socket head bolt to prevent the cable from press by the bolt





#### <Reference>


- Mount the emitter and the receiver at the same level and parallel to each other. The effective aperture angle of this device is  $\pm 2.5^\circ$  or less for a sensing distance of 3m or more.
- Unless otherwise specified, the following mounting procedure is common for both emitter and receiver. For the preparation of the mounting, prepare the mounting holes on the mounting surface by referring to "6-3 Dimensions."

#### <In case of using M8 rear mounting bracket (MS-SFB-7-T) (optional)>

1. Set the device with its mounting hole on the side just overlapping with the mounting hole of the M8 rear mounting bracket, and fix the M8 rear mounting bracket with the accessory hexagon-socket head bolt [M5 (length: 18mm)]. The tightening torque should be 1.2·Nm or less.




- Set the rear mounting bracket that is ready for setting to the mounting surface using two hexagon-socket head bolts [M8 (please arrange separately)].



Note: For the models that the intermediate supporting bracket (MS-SFB-2) is enclosed with, be sure to use the intermediate supporting bracket (MS-SFB-2). For details, refer to **<In case of using intermediate supporting bracket (MS-SFB-2) (accessory)>**.


#### <Reference>

- Mounting method of the M8 side mounting bracket (MS-SFB-8-T) and the M8 rear / side mounting bracket set (MS-SFB-1-T2) is the same as the M8 rear mounting bracket (MS-SFB-7-T).
- Take care that the shape of the M8 side mounting bracket (MS-SFB-8-T) for the device top and for the device bottom is different.
- M8 rear / side mounting bracket set (MS-SFB-1-T2) has been assembled for rear mounting at the factory shipment and the parts for side mounting are enclosed as accessories. In case of side mounting, remove the hexagon-socket head bolt for beam-axis alignment and mount the parts for side mounting.




**<In case of using M5 / M8 360°-rotatable mounting bracket (MS-SFB-1) (optional)>**


1. Loosen the low head cap screw for alignment [M5 (length: 6mm)] of the M5 / M8 360°-rotatable mounting bracket (**MS-SFB-1**).




2. As shown in the figure below, adjust the direction of this device and that of installation surface by declining the bracket, and tighten and fix the low head cap screw for alignment. The tightening torque should be 2N·m or less.




The marks are engraved on the M5 / M8 360°-rotatable mounting bracket so as to adjust the direction of this device by 30 degrees. Set and fix both emitter and receiver using the marks so that they face to each other.




**<In case of rear mounting>**



**<In case of side mounting>**




3. Set the device with its mounting hole on the side just overlapping with the mounting hole of the M5 / M8 360°-rotatable mounting bracket, and fix the M5 / M8 360°-rotatable mounting bracket with the accessory hexagon-socket head bolt [M5 (length: 16mm)]. The tightening torque should be 1.2N·m or less.



- Set the M5 / M8 360°-rotatable mounting bracket (**MS-SFB-1**) that is ready for setting to the mounting surface using either four hexagon-socket head bolts [M5 (please arrange separately)] or two hexagon-socket head bolts [M8 (please arrange separately)].

Hexagon-socket head bolt  
[M5 (please arrange separately)]

Hexagon-socket head bolt  
[M8 (please arrange separately)]



Note: For the models that the intermediate supporting bracket (**MS-SFB-2**) is enclosed with, be sure to use the intermediate supporting bracket (**MS-SFB-2**). For details, refer to **<In case of using intermediate supporting bracket (MS-SFB-2) (accessory)>**.

#### **<Reference>**

Mounting method of the M8 360°-rotatable mounting bracket (**MS-SFB-1-T**), M5 pitch adapter bracket (**MS-SFB-4**) and the M8 pitch adapter bracket (**MS-SFB-4-T**) is the same as the M5 / M8 360°-rotatable mounting bracket (**MS-SFB-1**).




**<In case of using dead zoneless mounting bracket (MS-SFB-3) (optional)>**


1. Set the spacer attached to the dead zoneless mounting bracket (MS-SFB-3) onto the mounting hole on the side of the top (bottom) end part of this device, and insert the hexagon-socket head bolt [M4 (length: 25mm)] into the hole.

**<In case of rear mounting>**

Spacer  
(Enclosed with **MS-SFB-3**)




**<In case of side mounting>**




2. Adjust the hexagon-socket head bolt with the status described in Step 1 to the mounting hole of the dead zoneless mounting bracket, and tighten and fix the bracket. The tightening torque should be 1.2N·m or less.

**<In case of rear mounting>**




**<In case of side mounting>**




3. Set the dead zoneless mounting bracket that is ready for setting to the mounting surface using four hexagon-socket head bolts [M5 (please arrange separately)].

**<In case of rear mounting>**




**<In case of side mounting>**



Note: For the models that the intermediate supporting bracket (MS-SFB-2) is enclosed with, be sure to use the intermediate supporting bracket (MS-SFB-2). For details, refer to **<In case of using intermediate supporting bracket (MS-SFB-2) (accessory)>**.


**<In case of using intermediate supporting bracket (MS-SFB-2) (accessory)>**

1. Loosen the hexagon-socket head bolt [M4 (length: 12mm)] screw of the intermediate supporting bracket (**MS-SFB-2**).




2. Insert the side of this device into the intermediate supporting bracket, and fix it with the hexagon-socket head bolt [M4 (length: 12mm)]. The tightening torque should be 1.2N·m or less.

Refer to “**6-3 Dimensions**” for the mounting position of the intermediate supporting bracket.




When setting the intermediate supporting bracket on both side surfaces of this device, fit the four pits and projectiles of both side surfaces of the main body to those of both side surfaces (inner surfaces) of the intermediate supporting bracket.

3. After aligning the beam axis, mount the intermediate supporting bracket to the mounting surface using two hexagons-socket head bolts [M5 (please arrange separately)].  
For the details of beam-axis alignment, refer to “**2-6-1 Beam-axis Alignment.**”



### <Mounting protection bar set (MC-SFBH-□-T) (optional)>


1. Mount the protection bar mounting bracket with the accessory two hexagon-socket head bolts [M5 (length: 18mm)]. The tightening torque should be 1.2N·m or less.
2. Mount the protection bar to the protection bar mounting bracket with a hexagon-socket head bolt [M5 (length: 20mm)]. The tightening torque should be 3N·m or less.
3. If the intermediate supporting bracket is used, mount the bracket with two hexagon-socket bolts [M5 (please arrange separately)] on the mounting surface temporarily. Furthermore, if the protection bar intermediate supporting bracket (**MS-SFB-6**) (optional) is used, also mount the bracket with a hexagon-socket bolt [M8 (please arrange separately)] on the mounting surface temporarily.
4. Mount the protection bar mounting bracket with a hexagon-socket bolt [M8 (please arrange separately)] on the mounting surface temporarily.
5. Adjust the angle of the emitter and the receiver horizontally within the adjustable range of the elongate hole, and tighten the hexagon-socket bolt [M8 (please arrange separately)].
6. Adjust the intermediate supporting bracket and protection bar intermediate supporting bracket, and then tighten the hexagon-socket bolt [M8 (please arrange separately)].



### <Reference>

Protection bar mounting bracket has been assembled for rear mounting at the factory shipment and the parts for side mounting are enclosed as accessories. In case of side mounting, remove the hexagon-socket head bolt for beam-axis alignment and mount the parts for side mounting.

#### <At factory shipment>



## 2-4-2 Mounting of the Bottom Cap Cable (Optional)

The cable is not enclosed with this device.

Mount the bottom cap cable (optional) in accordance with the following procedure.

### **CAUTION**

- Do not lose any screws during extension / dismantling.
- The bottom cap cables are distinguished with the color of the connectors, the color of the connector for emitter is gray and that of the receiver is black. Connect the cable to emitter and receiver without fail using their colors as the guide.

### <Reference>


There are two types of the bottom cap cable, discrete wire type and connector type. Select the bottom cap cable as usage.

The length of the bottom cap cable differs depending on the model No.


Type	Model No.	Cable length (m)
8-core	SFB-CCB3	3
	SFB-CCB7	7
	SFB-CCB10	10
	SFB-CCB15	15
	SFB-CB05	0.5
	SFB-CB5	5
	SFB-CB10	10

### <Mounting method>

1. Insert the connector of the bottom cap cable (optional) into the connector of this device.  
When inserting the connector, fit the cable to the groove of this device.



2. Tighten the two M2.6 screws. The tightening torque should be 0.3N·m or less.



## 2-4-3 Extension and Dismantling of Sensor (Series Connection)

This section describes the extension method of the series connection using the options.  
For constructing the series connection, the following procedure is required.


### **CAUTION**

Do not lose any screws during extension / dismantling work.  
Furthermore, do not mix emitters and receivers to mount in series connection.


#### <Mounting method of cable for series connection>

Replace the cable for series connection (**SFB-CSL□**).


1. Loosen the two M2.6 screws of the end cap on the main sensor (emitter and receiver to which the synchronization line has been connected), and then remove the end cap from the device.



2. Insert the connector of the cable for series connection (**SFB-CSL□**) (optional) into the connector. When inserting the connector, fit the cable into the groove of this device.




3. Tighten each two M2.6 screws. The tightening torque should be 0.3N·m or less.




## ⚠ CAUTION

- Take care that the shape of the connectors for the bottom side and for the end cap side on the cable for series connection (**SFB-CSL□**) is different.
- The cable for series connection (**SFB-CSL□**) cannot be extended.
- When the cable for series connection (**SFB-CSL□**) is inserted to the main sensor, take care of the following. If inserted without care, the connector pins may bend.

1) Do not insert the connector part aslant.



2) Do not pull the cables before tightening the M2.6 screws.



3) Do not insert the connector incorrectly and tighten the M2.6 screws.



### <Reference>

There is no difference in the cable for series connection for the emitter and the receiver.  
The length of the cable for series connection differs depending on the model No.

Model No.	Cable Length (mm)
<b>SFB-CSL01</b>	100
<b>SFB-CSL05</b>	500
<b>SFB-CSL1</b>	1,000
<b>SFB-CSL5</b>	5,000

### <Dismantling the cable for series connection>

1. For dismantling the cable for series connection, follow the above procedure of **<Mounting method of cable for series connection>** in reverse.

## 2-5 Wiring

### **WARNING**

- Earth the machine or the support where the device is mounted on to frame ground (F.G.). Failure to do so could cause the malfunction of the device by noise, resulting in death or serious injury.  
Furthermore, the wiring should be done in a metal box connected to the frame ground (F.G.).
- Take countermeasure against the system to be applied for this device so as not to carry out the dangerous performance caused by the earth failure. Failure to do so could cause invalid for the system stop, resulting in death or serious injury.
- In order that the output is not turned ON due to earth fault of control output (OSSD 1 / 2) wires, be sure to ground to 0V side (PNP output) / +24V side (NPN output).

### **CAUTION**

Make sure to insulate the ends of the unused lead wires.

#### <Reference>

Use a safety relay unit or an equivalent control circuit in safety for FSD.

## 2-5-1 Power Supply Unit

### **WARNING**

Wire correctly using a power supply unit which conforms to the laws and standards of the region where this device is to be used. If the power supply unit is non-conforming or the wiring is improper, it can cause damage or malfunction of this device.

#### <Reference>


A specialist who has the required electrical knowledge should perform the wiring.

The power supply unit must satisfy the conditions given below.

- 1) Power supply unit authorized in the region where this device is to be used.
- 2) Power supply unit SELV (safety extra low voltage) / PELV (protected extra low voltage) conforming to EMC Directive and Low-voltage Directive (only for requiring CE marking conformation).
- 3) Power supply unit conforming to the Low-voltage Directive and with an output of 100VA or less.
- 4) The frame ground (F.G.) terminal must be connected to ground when using a commercially available switching regulator.
- 5) Power supply unit with an output holding time of 20ms or more.
- 6) In case a surge is generated, take countermeasures such as connecting a surge absorber to the origin of the surge.
- 7) Power supply unit corresponding to CLASS 2 (only for requiring UL Listing Mark / C-UL US Listing Mark conformation).

## 2-5-2 I/O Circuit Diagrams and Output Waveform

<In case of using I/O circuit for PNP output>



\*S1

Switch S1

- Emission halt input / Reset input  
For manual reset: Vs to Vs - 2.5V (sink current 5mA or less) : Emission halt (Note 1), Open: Emission  
For auto-reset: Vs to Vs - 2.5V (sink current 5mA or less) : Emission (Note 1), Open: Emission halt
- Interlock setting input, External device monitor input  
Vs to Vs - 2.5V (sink current 5mA or less): Valid (Note), Open: Invalid


Note: Vs is the applying supply voltage.

### <Reference>

K1, K2: External device (Forced guided relay or magnetic contactor)



### <In case of using I/O circuit for NPN output>



\*S1

Switch S1

- Emission halt input / Reset input  
For manual reset: 0 to +1.5V (source current 5mA or less): Emission halt, Open: Emission  
For auto-reset: 0 to +1.5V (source current 5mA or less): Emission, Open: Emission halt
- Interlock setting input, External device monitor input  
0 to +1.5V (source current 5mA or less): Valid, Open: Invalid

### <Reference>

K1, K2: External device (Forced guided relay or magnetic contactor)


### <Output waveform [control output (OSSD 1 / 2) ON]>

Since the receiver performs the self-diagnosis of the output circuit when the device is in light receiving status (ON status), the output transistor becomes OFF status periodically. (Refer to the figure below.) When the OFF signal is fed back, the receiver judges the output circuit as normal. When the OFF signal is not fed back, the receiver judges either the output circuit or wiring as error, and the control output (OSSD 1 / 2) maintains OFF status.

### CAUTION

Perform the wiring with paying attention to the input response time of the machine to be connected to this device, since the OFF signal of this device might cause malfunction.

### <Timing chart>



## 2-5-3 Wiring · Connecting Procedure and Connector Pin Arrangement


Connect the mating cable (with connector on one end or connector on both ends) to the connector of the bottom cap cable which is mounted on this device (emitter and receiver).

Wire the other side of the mating cable according to the customer's application referring to the connector pin arrangement given below.


### WARNING

- When extending the cable, use the exclusive cable up to the total length of 50m (for each emitter / receiver). Extending the cable longer than 50m may cause malfunction, which can result in death or serious injury. Besides, if two sets of the devices are connected in series, up to total length of 30m (for each emitter / receiver) is allowed for use, and if three sets of the devices are connected, up to total length of 20m (for each emitter / receiver) is allowed for use. Extending the cable longer than the length specified may cause malfunction, which can result in death or serious injury.
- When the synchronization cable is extended with a cable other than exclusive cable, use a  $\phi 0.2\text{mm}^2$  or more shielded twisted pair cable.


Bottom cap cable / discrete wire




Bottom cap cable / connector




Extension cable with connector on one end



Extension cable with connector on both ends



Connector at A side (for emitter / receiver)



Connector at B side (for emitter / receiver)



**<8-core cable (SFB-CC□)>**

	Cable / connector color	Connector Pin No.	Color code	Description
Emitter	Gray / Gray	1	Pale purple	Interlock setting input
		2	Brown	+V
		3	Pink	Emission halt input / Reset input
		4	Yellow-green / Black	Auxiliary output
		5	Orange	Synchronization +
		6	Orange / Black	Synchronization -
		7	Blue	0V
		8	(Shield)	Output polarity setting wire
Receiver	Gray (with black stripe) /Black	1	White	Control output 2 (OSSD 2)
		2	Brown	+V
		3	Black	Control output 1 (OSSD 1)
		4	Yellow-green	External device monitor input
		5	Orange	Synchronization +
		6	Orange / Black	Synchronization -
		7	Blue	0V
		8	(Shield)	Output polarity setting wire

**<Reference>**

- The connectors can be distinguished from their colors as follows:  
Connector for emitter: gray, connector for receiver: black
- For details of the bottom cap cable, the cable with connector on one end, and the cable with connector on both ends, refer to “**6-2 Options.**”

## 2-5-4 Basic Wiring


This is the general configuration using one set of the emitter and receiver facing each other. The control output (OSSD 1 / 2) turns OFF if the light is blocked, while it automatically turns ON if it receives the light.

The auxiliary output is used to invalid the external device monitor function.

The auxiliary output is “negative logic of the control output (OSSD 1 / 2).”


The auxiliary output cannot be connected to external devices.

### <For PNP output>



Interlock function	Invalid (Auto-reset)
External device monitor function	Invalid
Auxiliary output	Cannot be used

<For NPN output>




Interlock function	Invalid (Auto-reset)
External device monitor function	Invalid
Auxiliary output	Cannot be used

## 2-5-5 Wiring for Manual Reset (Interlock is Valid) (Wiring Example of the Control Category 4)

This is the general configuration using one set of the emitter and receiver facing each other.  
The control output (OSSD 1 / 2) turns OFF if the light is blocked.

<For PNP output>



Interlock function	Valid (Manual reset)
External device monitor function	Valid
Auxiliary output	Can be used

The device output is selected depending on the connecting state of the output polarity setting wire (shield). Incorrect wiring may cause the lockout state.

\* Symbols

Switch S1


Vs to Vs - 2.5V (sink current 5mA or less): Emission halt (Note 1), Open: Emission

K1, K2: External device (Forced guided relay or magnetic contactor)

Notes: 1) Vs is the applying supply voltage.

2) For resetting, refer to "3-2 Interlock Function."

**<For NPN output>**



Interlock function	Valid (Manual reset)
External device monitor function	Valid
Auxiliary output	Can be used

The device output is selected depending on the connecting state of the output polarity setting wire (shield). Incorrect wiring may cause the lockout state.

\* Symbols

Switch S1

0 to +1.5V (source current 5mA or less): Emission halt, Open: Emission

K1, K2: External device (Forced guided relay or magnetic contactor)

Note: For resetting, refer to “3-2 Interlock Function.”

## 2-5-6 Series Connection (Wiring Example of the Control Category 4)


[Connectable up to 3 sets of the devices (however, 192 beam channels max.)]

This is the configuration for connecting multiple sets of emitters and receivers facing each other in series. It is used when the dangerous part can be entered from two or more directions. If any of the sets is in light blocked status, the control output (OSSD 1 / 2) turns OFF.

### **⚠ WARNING**

For series connection, connect the emitter and emitter, receiver and receiver respectively using the exclusive cable (**SFB-CSL**) for series connection. Wrong connection could generate the non-sensing area, resulting in death or serious injury.

<For PNP output>



Interlock function	Valid (Manual reset)
External device monitor function	Valid
Auxiliary output	Can be used

The device output is selected depending on the connecting state of the output polarity setting wire (shield). Incorrect wiring may cause the lockout state.

\* Symbols

Switch S1

Vs to Vs - 2.5V (sink current 5mA or less): Emission halt (Note 1), Open: Emission


K1, K2: External device (Forced guided relay or magnetic contactor)

Notes: 1) Vs is the applying supply voltage.

2) For resetting, refer to "3-2 Interlock Function."



<For NPN output>



Interlock function	Valid (Manual reset)
External device monitor function	Valid
Auxiliary output	Can be used

The device output is selected depending on the connecting state of the output polarity setting wire (shield). Incorrect wiring may cause the lockout state.


\* Symbols

Switch S1  
 0 to +1.5V (source current 5mA or less): Emission halt, Open: Emission  
 K1, K2: External device (Forced guided relay or magnetic contactor)

Note: For resetting, refer to "3-2 Interlock Function."

## 2-5-7 Wiring for Auto-reset (Interlock is Invalid) (Wiring Example of the Control Category 4)

<For PNP output>



Interlock function	Invalid (Auto-reset)
External device monitor function	Valid
Auxiliary output	Can be used

The device output is selected depending on the connecting state of the output polarity setting wire (shield). Incorrect wiring may cause the lockout state.

\* Symbols

Switch S1


Vs to Vs - 2.5V (sink current 5mA or less): Emission (Note 1), Open: Emission halt

K1, K2: External device (Forced guided relay or magnetic contactor)

Notes: 1) Vs is the applying supply voltage.

2) For resetting, refer to "3-2 Interlock Function."

<For NPN output>



Interlock function	Invalid (Auto-reset)
External device monitor function	Valid
Auxiliary output	Can be used

The device output is selected depending on the connecting state of the output polarity setting wire (shield). Incorrect wiring may cause the lockout state.

\* Symbols


Switch S1  
 0 to +1.5V (source current 5mA or less): Emission, Open: Emission halt  
 K1, K2: External device (Forced guided relay or magnetic contactor)

Note: For resetting, refer to "3-2 Interlock Function."

## 2-5-8 Wiring Configuration for Invalid External Device Monitor Function (Wiring Example of the Control Category 4)

Connect auxiliary output and external device monitor input.  
The auxiliary output is "negative logic of the control output (OSSD 1 / 2)."  
The auxiliary output cannot be connected to external devices.

<For PNP output>



Interlock function	Invalid (Auto-reset)
External device monitor function	Invalid
Auxiliary output	Cannot be used


The device output is selected depending on the connecting state of the output polarity setting wire (shield). Incorrect wiring may cause the lockout state.

\* Symbols

Switch S1  
Vs to Vs - 2.5V (sink current 5mA or less): Emission (Note 1), Open: Emission halt  
K1, K2: External device (Forced guided relay or magnetic contactor)

Note: Vs is the applying supply voltage.

<For NPN output>



Interlock function	Invalid (Auto-reset)
External device monitor function	Invalid
Auxiliary output	Cannot be used

The device output is selected depending on the connecting state of the output polarity setting wire (shield). Incorrect wiring may cause the lockout state.

\* Symbols

Switch S1

0 to +1.5V (source current 5mA or less): Emission, Open: Emission halt

K1, K2: External device (Forced guided relay or magnetic contactor)


## 2-6 Adjustment

### 2-6-1 Beam-axis Alignment


1. Turn ON the power supply unit of this device.
2. Check that the digital error indicator (red) and the fault indicator (yellow) of the emitter and receiver are OFF respectively.  
If the digital error indicator (red) or the fault indicator (yellow) lights up or blinks, refer to **"Chapter 5 Troubleshooting"** and report the symptoms to the maintenance in charge.
3. In case of using the intermediate supporting bracket (**MS-SFB-2**), loosen the two hexagon-socket head bolt [M5 (please arrange separately)].
4. Loosen the hexagon-socket head bolt for beam axis alignment of the mounting bracket, and adjust the emitter / receiver so that the beam-axis alignment indicators in the display of the emitter and receiver light up.

The emitter and the receiver can be fine-adjusted by  $\pm 15$  degrees.

<In case of MS-SFB-7-T>



<In case of MS-SFB-1>




## <Reference>

The beam-axis alignment indicator indicates the reception status for each section of the device which is divided into 4 sections.

Also, the A (D) of the beam-axis alignment indicates the light-receiving status of the device top end (bottom end).

For example, when using a 24-beam channel device, there are 6 beam channels per section (i.e.,  $24/4=6$ ). When the top end (bottom end) beam channel is received, the A (D) of the beam-axis alignment indicator blinks in red.

(Example) 24 beam channels



All the 6 beam channels divided into each section are received, the beam-axis alignment indicator lights up in red.

The indicators corresponding to the different sections light up in red, one by one, when the beam channels of the respective sections are received. When all the beam channels are received and the control output (OSSD 1 / 2) turns ON, all the four indicators of the beam-axis alignment indicator turn into green.

Refer to “2-6-2 Operation Test” for details.


- After the adjustment, tighten the hexagon-socket head bolt for beam-axis alignment of the mounting bracket. The tightening torque should be 2N·m or less.
- Tighten the two intermediate supporting brackets [M5 (please arrange separately)]. Check, once again, that the beam-axis alignment indicators in the display of the emitter and receiver do light up.

## ⚠ CAUTION

After the beam-axis alignment is finished, make sure to confirm that all the bolts are tightened by the specified torque. For the tightening torque of each bolt, refer to “2-4 Mounting.”

## 2-6-2 Operation Test

1. Turn ON the power supply unit of this device.
2. Check that the digital error indicator (red) and the fault indicator (yellow) of the emitter and the receiver are OFF respectively.  
If the digital error indicator (red) or the fault indicator (yellow) lights up or blinks, refer to “**Chapter 5 Troubleshooting**,” and report the symptoms to the maintenance in charge.
3. Move the test rod ( $\varnothing 14\text{mm}$  for **SF4B-F□-03<V2>**,  $\varnothing 25\text{mm}$  for **SF4B-H□-03<V2>**) up and down less than 1,600mm/sec at three positions, just in front of the emitter (A), between the emitter and receiver (B), and just in front of the receiver (C).



4. During Step 3 above, check that the control output (OSSD 1 / 2) is in OFF state, and both the OSSD indicator (red) of the receiver and the operation indicator (red) of the emitter light up as long as the test rod is present within the sensing area.
  - If the behavior of the control output (OSSD 1 / 2) and the turning ON / OFF of the emitter / receiver indicators do not correspond to the movement of the test rod, refer to “**Chapter 5 Troubleshooting**,” and report the symptoms to the maintenance in charge.

### <Reference>

If the indicators show reception of the light even though the test rod blocks the light, check whether there is any reflective object or extraneous light source near this device or not.























































## 2-6-3 Operation

### 1) Normal Operation

The status of the emitter / receiver indicators during normal operation is as described below.


















































: Blinks in red    
 : Lights up in red    
 : Lights up in green    
 : Lights up in orange    
 : Turns OFF

Device status		Indicators				Control output	
		Emitter		Receiver		OSSD 1	OSSD 2
Light received status (all beams received)		Beam-axis alignment indicator (Green)	   	Beam-axis alignment indicator (Green)	   	ON	
		Operation indicator (Green) (Note 1)		OSSD indicator (Green)			
		Incident light intensity indicator (Green)		Incident light intensity indicator (Green)			
		Fault indicator		Fault indicator			
		Digital error indicator	 	Digital error indicator	 		
		PNP indicator (Orange) (Note 2)		PNP indicator (Orange) (Note 2)			
		NPN indicator		NPN indicator			
		Emission intensity control indicator		Function setting indicator			
		Emission halt indicator		Interlock indicator			
Light blocked status	One or more lights blocked	Beam-axis alignment indicator (Red)	   	Beam-axis alignment indicator (Red)	   	OFF	
		Operation indicator (Red) (Note 1)		OSSD Indicator (Red)			
		Incident light intensity indicator		Incident light intensity indicator			
		Fault indicator		Fault indicator			
		Digital error indicator	 	Digital error indicator	 		
		PNP indicator (Orange) (Note 2)		PNP indicator (Orange) (Note 2)			
		NPN indicator		NPN indicator			
		Emission intensity control indicator		Function setting indicator			
		Emission halt indicator		Interlock indicator			

Notes: 1) Since the color of the operation indicator changes according to the ON / OFF state of the control output (OSSD 1 / 2), the operation indicator is marked as OSSD on the device.

2) The status of the emitter / receiver indicators during operation above shows the case in PNP output setting mode. In case of NPN output setting mode, the NPN indicator (orange) lights up.

: Blinks in red   
 : Lights up in red   
 : Lights up in green   
 : Lights up in orange   
 : Turns OFF

Device status		Indicators		Control output			
		Emitter		Receiver		OSSD 1	OSSD 2
Light blocked status	Lights other than the top end blocked	Beam-axis alignment indicator (Red)     Operation indicator (Red) (Note 1)  Incident light intensity indicator  Fault indicator  Digital error indicator  PNP indicator (Orange) (Note 2)  NPN indicator  Emission intensity control indicator  Emission halt indicator 		Beam-axis alignment indicator (Red)     OSSD indicator (Red)  Incident light intensity indicator  Fault indicator  Digital error indicator  PNP indicator (Orange) (Note 2)  NPN indicator  Function setting indicator  Interlock indicator 	OFF		
	Lights other than the bottom end blocked	Beam-axis alignment indicator (Red)     Operation indicator (Red) (Note 1)  Incident light intensity indicator  Fault indicator  Digital error indicator  PNP indicator (Orange) (Note 2)  NPN indicator  Emission intensity control indicator  Emission halt indicator 		Beam-axis alignment indicator (Red)     OSSD indicator (Red) (Note 1)  Incident light intensity indicator  Fault indicator  Digital error indicator  PNP indicator (Orange) (Note 2)  NPN indicator  Function setting indicator  Interlock indicator 	OFF		
Time chart							

Notes: 1) Since the color of the operation indicator changes according to the ON / OFF state of the control output (OSSD 1 / 2), the operation indicator is marked as "OSSD" on the device.

2) The status of the emitter / receiver indicators during operation above shows the case in PNP output setting mode. In case of NPN output setting mode, the NPN indicator (orange) lights up.

### <For series connection>


In case of series connection, if any of the sets is in light blocked status, the control output (OSSD 1 / 2) turns OFF.

### <Reference>

The emitter / receiver indicators indicates the output status.

The following figure shows the status of the indicators with Sub sensor 2 in light blocked status.

■: Lights up in red ■: Lights up in orange □: Turns OFF



Notes: 1) Since the color of the operation indicator changes according to the ON / OFF state of the control output (OSSD 1 / 2), the operation indicator is marked as "OSSD" on the device.

2) The status of the emitter / receiver indicators during operation above shows the case in PNP output setting mode. In case of NPN output setting mode, the NPN indicator (orange) lights up.



































## 2) When using emission halt function

This device incorporates the emission halt function. Using this function, it is possible to simulate the light blocked status.

### <Reference>

When the emission halt input is kept open (for manual reset: connected to 0V, +V), the emitter stops emitting light. In this condition, if this device operates properly, the control output (OSSD 1 / 2) of the receiver turns OFF.

 : Blinks in orange    
  : Lights up in red    
  : Lights up in green    
  : Lights up in orange    
  : Turns OFF

Setting procedure and check items		Indicators				Control output	
		Emitter		Receiver		OSSD 1	OSSD 2
1	Before power is ON, Connect the emission halt input / Reset input to Vs. (Note 3)	Beam-axis alignment indicator		Beam-axis alignment indicator		OFF	
		Operation indicator (Note 1)		OSSD indicator			
		Incident light intensity indicator		Incident light intensity indicator			
		Fault indicator		Fault indicator			
		Digital error indicator		Digital error indicator			
		PNP indicator		PNP indicator			
		NPN indicator		NPN indicator			
		Emission intensity control indicator		Function setting indicator			
2	After power is ON, Receiver's control output (OSSD 1 / 2) is ON. (Normal operation)	Beam-axis alignment indicator (Green)		Beam-axis alignment indicator (Green)		ON	
		Operation indicator (Green) (Note 1)		OSSD indicator (Green)			
		Incident light intensity indicator (Green)		Incident light intensity indicator (Green)			
		Fault indicator		Fault indicator			
		Digital error indicator		Digital error indicator			
		PNP indicator (Orange) (Note 2)		PNP indicator (Orange) (Note 2)			
		NPN indicator		NPN indicator			
		Emission intensity control indicator		Function setting indicator			
		Emission halt indicator		Interlock indicator			

Notes: 1) Since the color of the operation indicator changes according to the ON / OFF state of the control output (OSSD 1 / 2), the operation indicator is marked as "OSSD" on the device.


2) The status of the emitter / receiver indicators during operation above shows the case in PNP output setting mode. In case of NPN output setting mode, the NPN indicator (orange) lights up.

3) Vs is the applying supply voltage.

### 3) When an error occurs

If a device error is detected, the device will turn the control output (OSSD 1 / 2) OFF. Then the digital error indicator (red) on the receiver lights up and the fault indicators (yellow) on the emitter and receiver light up or blink.

- If an emitter error is detected, the emitter will be locked out, stopping its emission, and the control output (OSSD 1 / 2) will be turned OFF.
- If a receiver error is detected, the receiver will be locked out, and the control output (OSSD 1 / 2) will go into OFF state. Also, the emission halt indicator (orange) of the emitter lights up.



Notes: 1) Since the color of the operation indicator changes according to the ON / OFF state of the control output (OSSD 1 / 2), the operation indicator is marked as "OSSD" on the device.

2) Refer to "**Chapter 5 Troubleshooting**" for details of the digital error indicator.



































3) The status of the emitter / receiver indicators during operation above shows the case in PNP output setting mode. In case of NPN output setting mode, the NPN indicator (orange) lights up.

Since this device will not return to normal operation automatically after the removal of the source of error, it is necessary to turn the power OFF and ON again.

(Source of error): The control output (OSSD 1 / 2) short-circuit, extraneous light detection, sensor failure, etc.

Refer to "**Chapter 5 Troubleshooting**" and remove the source of error.

: Blinks in orange    
 : Lights up in red    
 : Lights up in green    
 : Lights up in orange    
 : Turns OFF

Setting procedure and check items		Indicators		Control output	
		Emitter	Receiver	OSSD 1	OSSD 2
3	Open the emission halt input / reset output. Receiver's control output (OSSD 1 / 2) is OFF. (Emission halt) (Normal operation)	Beam-axis alignment indicator 	Beam-axis alignment indicator 	OFF	
		Operation indicator (Red) (Note 1) 	OSSD indicator (Red) 		
		Incident light intensity indicator 	Incident light intensity indicator 		
		Fault indicator 	Fault indicator 		
		Digital error indicator 	Digital error indicator 		
		PNP indicator (Orange) (Note 2) 	PNP indicator (Orange) (Note 2) 		
		NPN indicator 	NPN indicator 		
		Emission intensity control indicator 	Function setting indicator 		
4	Connect the emission halt input to Vs. (Note 3) Receiver's control output (OSSD 1 / 2) is ON. (Normal operation)	Beam-axis alignment indicator (Green) 	Beam-axis alignment indicator (Green) 	ON	
		Operation indicator (Green) (Note 1) 	OSSD indicator (Green) 		
		Incident light intensity indicator (Green) 	Incident light intensity indicator (Green) 		
		Fault indicator 	Fault indicator 		
		Digital error indicator 	Digital error indicator 		
		PNP indicator (Orange) (Note 2) 	PNP indicator (Orange) (Note 2) 		
		NPN indicator 	NPN indicator 		
		Emission intensity control indicator 	Function setting indicator 		
		Emission halt indicator (orange) 	Interlock indicator 		

Notes: 1) Since the color of the operation indicator changes according to the ON / OFF state of the control output (OSSD 1 / 2), the operation indicator is marked as "OSSD" on the device.

2) The status of the emitter / receiver indicators during operation above shows the case in PNP output setting mode. In case of NPN output setting mode, the NPN indicator (orange) lights up.

3) Vs is the applying supply voltage.

## Chapter 3 Functions

### 3-1 Self-diagnosis Function

This device incorporates the self-diagnosis function.

The self-diagnosis is carried out when the power is turned ON and while the operation periodically.

In case an abnormality is detected during self-diagnosis, the device is put in the lockout state at that instant, and the control output (OSSD 1 / 2) is fixed at the OFF state. Refer to “**Chapter 5 Troubleshooting**” and remove the cause of the abnormality.

### 3-2 Interlock Function

The selection of manual reset / auto reset is available by applying the interlock input wiring. The interlock becomes available by selecting manual reset.


Interlock setting input wire (pale purple)	Setting for interlock function
In case of selecting PNP output: connect to +V In case of selecting NPN output: connect to 0V	Manual reset
Open	Auto reset

#### **⚠ WARNING**

In case of using the interlock function, be sure there exists no operator inside of the dangerous area. it causes death or serious injury without the confirmation.

**Manual reset:** The control output (OSSD 1 / 2) is not turned ON automatically even though this device is received the light. When this device is reset in light received state [open the emission halt input / reset input → short-circuit the device to 0V or +V → open], the control output (OSSD 1 / 2) is turned ON.

#### <Timing chart>



#### **⚠ WARNING**

The reset switch shall be placed in area where all over the dangerous zone shall be comprehend and out side of the dangerous zone.

**Auto-reset:** The control output (OSSD 1 / 2) is turned ON automatically when this device receives the light.

#### **⚠ WARNING**

If this device is used with the auto-reset, avoid an auto-restart after the safety output stop of the system by using a safety relay unit, etc. (EN 60204-1)

### 3-3 Emission Halt Function

This function stops the emission process of the emitter.


With the emission halt input line state, it enables to select either emission or emission halt.

Setting status of interlock function	Emission halt input / Reset input	Emission halt input	Control output (OSSD 1 / 2) status
Manual reset	Open	Invalid	ON
	When selecting PNP output: connect to +V When selecting NPN output: connect to 0V	Valid	OFF
Auto reset	Open	Valid	OFF
	When selecting PNP output: connect to +V When selecting NPN output: connect to 0V	Invalid	ON

During emission halt, the control output (OSSD 1 / 2) becomes OFF state.

By using this function, malfunction due to extraneous noise or abnormality in the control output (OSSD 1 / 2) and the auxiliary output can be determined even from the equipment side.

Normal operation is restored when the emission halt input / reset input is connected to 0V or +V (for manual reset: open).



Note: This timing chart shows the operation in auto-reset mode. In manual reset mode, the device performs emission under open status and performs emission halt under short-circuit status.



**WARNING**

Do not use the emission halt function for the purpose of stopping the machine in which the **SF4B-□-03<V2>** series is installed. Failure to do so could result in death or serious injury.


### 3-4 Interference Prevention Function

It is possible to construct the system to prevent malfunction due to interference of the light between **SF4B-□-03<V2>** series devices.

The interference prevention system can construct max. three sets of series.

The max. number of the beam channels in series connection is 192.

Refer to “**2-5 Wiring**” for details of the connecting method.






### 3-5 Auxiliary Output (Non-safety Output)

This device incorporates the auxiliary output for the non-safety output.  
The auxiliary output is incorporated in the emitter.

Auxiliary output	Normal mode			Lockout
	Emission halt	Control output (OSSD 1 / 2) status		
		Light received	Light blocked	
Negative logic of OSSD (Factory setting)	ON	OFF	ON	ON

#### <Timing chart>



#### WARNING

Do not use the auxiliary output for the purpose of stopping the machine in which the **SF4B-□-03<V2>** is installed. Failure to do so could result in death or serious injury.

### 3-6 External Device Monitor Function

This is the function for checking whether the external safety relay connected to the control output (OSSD 1 / 2) performs normally in accordance with the control output (OSSD 1 / 2) or not. Monitor the contacting point "b" of the external safety relay, and if any abnormality such as deposit of the contacting point, etc. is detected, change the status of the device into lockout one, and turn OFF the control output (OSSD 1 / 2).

- **When the external device monitor function is set to be valid:**

Connect the external device monitor input wire (yellow-green) to the external safety relay which is connected to the control output 1 (OSSD 1) wire (black) and the control output 2 (OSSD 2) wire (white).


- **When the external device monitor function is set to be invalid:**

Connect the external device monitor input wire (yellow-green) to the auxiliary output wire (yellow-green / black).

The auxiliary output is set as [negative logic of control output (OSSD 1 / 2)].


In case the external device monitor input function is invalid, the auxiliary output cannot be connected to external devices.

### <Timing chart (Normal)>




The setting time of the device monitor is 300ms or less. Exceeding 300ms turns the device into lockout status.

### <Timing chart (Error 1)>



### <Timing chart (Error 2)>



# Chapter 4 Maintenance

## <Reference>

When any errors are found, refer to “**Chapter 5 Troubleshooting**” and report the symptoms to the maintenance in charge. If the rectification method is not clear, please contact our office.  
Please make a copy of this checklist, check each inspection item in the respective square, and file the list for record.

## 4-1 Daily Inspection




### WARNING

Be sure to inspect the following items prior to operation and confirm that there is no error.

Operating this device without inspection or in an error condition can result in death or serious injury.

### Check list (Daily inspection)

Check column	Inspection item
<input type="checkbox"/>	Dangerous parts of the machine cannot be reached without passing through the sensing area of this device.
<input type="checkbox"/>	Some part of operator's body remains in the sensing area when operation is done with dangerous parts of the machine.
<input type="checkbox"/>	The calculated safety distance has been maintained or exceeded during installation.
<input type="checkbox"/>	There is no damage to the safety guard or protective structure.
<input type="checkbox"/>	There is no defect, fold, or damage in the wiring.
<input type="checkbox"/>	The corresponding connectors have been connected securely.
<input type="checkbox"/>	No dirt or scratches exist on the light emitting surface.
<input type="checkbox"/>	The test rod is not deformed or defective.
<input type="checkbox"/>	The operation indicator (green) of the emitter and the OSSD indicator (green) of the receiver light up when no object is present in the sensing area. The control output (OSSD 1 / 2) is in ON status. At this time, the effect of external noise can be inspected. In case external noise affects the operation, remove its cause and reinspect.
<input type="checkbox"/>	<p>The test rod (ø14mm for <b>SF4B-F□-03&lt;V2&gt;</b> or ø25mm for <b>SF4B-H□-03&lt;V2&gt;</b>) can be detected less than 1,600mm/sec at three positions, directly in front of the emitter (A), midway between the emitter and the receiver (B), and directly in front of the receiver (C). The OSSD indicator (red) of the receiver and the operation indicator (red) of the emitter continue to light up as long as the test rod is present in the sensing area from (A) to (C).</p> 
<input type="checkbox"/>	With the machine in the operating condition, the dangerous parts operate normally when no object is present in the sensing area.
<input type="checkbox"/>	With the machine in the operating condition, the dangerous parts stop immediately when the test rod is inserted into the sensing area at any of the three positions, directly in front of the emitter (A), midway between the emitter and the receiver (B), and directly in front of the receiver (C).
<input type="checkbox"/>	The dangerous parts remain stopped as long as the test rod is present in the sensing area.
<input type="checkbox"/>	The dangerous parts stop immediately when the power supply of this device is turned OFF.
<input type="checkbox"/>	The control output (OSSD 1 / 2) must turn OFF when the emission halt input / reset input wire (pink) is open (for manual reset: connected to 0V, +V). At this time, the effect of external noise can be inspected. In case external noise affects the operation, remove its cause and reinspect.

## 4-2 Periodic Inspection (Every Six Months)

### **WARNING**

Be sure to inspect the following items every six months and confirm that there is no error. Operating this device without inspection or in an error condition can result in death or serious injury.

#### Check list (Periodic inspection)

Check column	Inspection item
<input type="checkbox"/>	The structure of the machine does not obstruct any safety mechanism for stopping operation.
<input type="checkbox"/>	No modification has been made in the machine controls which obstructs the safety mechanisms.
<input type="checkbox"/>	The output of this device is correctly detected.
<input type="checkbox"/>	The wiring from this device is correct.
<input type="checkbox"/>	The overall response time of the complete machine is equal or less than the calculated value.
<input type="checkbox"/>	The actual number of operation cycle (time) of the limited lifetime parts (relay, etc.) is less than their rated operation cycles (time).
<input type="checkbox"/>	No screws or connectors of this device are loose.
<input type="checkbox"/>	No extraneous light source or reflective object has been added near this device.

## 4-3 Inspection after Maintenance

Under the following situations, perform all the inspection items mentioned in “4-1 Daily Inspection” and “4-2 Periodic Inspection (Every Six Months).”

- 1) When any parts of this device are replaced.
- 2) When some abnormality is felt during operation.
- 3) When beam-axis alignment of the emitter and receiver is done.
- 4) When the device installation place or environment is changed.
- 5) When the wiring method or wiring layout is changed.
- 6) When FSD (Final Switching Device) parts are replaced.
- 7) When FSD (Final Switching Device) setting is changed.

## Chapter 5 Troubleshooting

### <Reference>

- Check the wiring.
- Check the power supply voltage and the power supply capacity.

## 5-1 Troubleshooting of Emitter

### <All indicators are OFF>

Cause	Remedy
Power is not being supplied	Check that the power supply capacity is sufficient. Connect the power supply correctly.
Supply voltage is out of the specified range.	Set the supply voltage correctly.
Connector is not connected securely.	Connect the connector securely.

### <Fault indicator (yellow) lights or blinks>

Cause	Remedy
<b>[Digital error indicator: 0]</b> Setting data error of this device	Series connection is incorrect.
	Noise is out of the specified range.
	Internal error
<b>[Digital error indicator: 1]</b> System error between emitter and receiver	Set the same value to the numbers of emitter and receiver and that of beam channel, and the shield wires.
<b>[Digital error indicator: 2]</b> Series connection error	The serial signal short-circuits or comes down.
	Any of the main / sub sensor is in error.
<b>[Digital error indicator: 3]</b> No. of total units / No. of total beam channels error	Set the condition of the series connection within the specification. Refer to "2-5-6 Series Connection."
<b>[Digital error indicator: 4]</b> Interlock setting error	Wire the interlock setting input wire (pale purple), or emission halt input / reset input wire (pink) is unstable.
<b>[Digital error indicator: 5]</b> Output polarity setting wire (shield) error	Output polarity setting wire (shield) comes down or short-circuits with other I/O wires. Output polarity setting wire (shield) connection of emitter / receiver is incorrect.
<b>[Digital error indicator: F]</b> Effect from noise / power supply or failure of internal circuit	Affected by noise / power supply. Internal circuit is broken down.

### <Digital error indicator “ $\epsilon$ ” lights up>

Cause	Remedy
Synchronization + wire (orange) or synchronization - wire (orange / black) error. Synchronization + wire (orange) or synchronization - wire (orange / black) comes down or short-circuits.	Connect synchronization + wire (orange) or synchronization + wire (orange / black) properly. Refer to “ <b>2-5 Wiring.</b> ”
Receiver error	Check the operation of the receiver side.

### <Emission halt indicator (orange) lights up>

Cause	Remedy
Emission is in halt condition (Device error or interlock setting error)	Error indicator (yellow) lights or blinks.
	Check the contents of the digital error indicator.
	Emission halt input / reset input wire (pink) is open when selecting auto-reset. Wire the emission halt input / reset input (pink) wire to 0V or +V. Refer to “ <b>2-5 Wiring.</b> ”
	Emission halt input / reset input wire (pink) is connected to 0V or +V when selecting manual reset. Open the emission halt input / reset input (pink) wire. Refer to “ <b>2-5 Wiring.</b> ”

### <Operation indicator remains lit in red (light is not received) (Note)>

Cause	Remedy
The beam channels are not correctly aligned.	Align the beam channels. Refer to “ <b>2-6 Adjustment.</b> ” Align the top / bottom direction of the beam channel between emitter and receiver.

Note: Since the color of the operation indicator changes according to ON / OFF status of the control output (OSSD 1 / 2), the operation indicator is marked as “OSSD” on the device.

If the device does not work normally after checking the items above, please consult Panasonic Electric Works SUNX.

## 5-2 Troubleshooting of Receiver

### <All indicators are OFF>

Cause	Remedy
Power is not being supplied.	Check that the power supply capacity is sufficient. Connect the power supply correctly.
Supply voltage is out of the specified range.	Set the supply voltage correctly.
Connector is not connected securely.	Connect the connector securely.

### <Fault indicator (yellow) lights or blinks>

Cause		Remedy
[Digital error indicator: 0] Setting data error of this device	Series connection is incorrect.	Check that the cable for series connection does not short-circuit, or is connected to the correct position (emitter for emitter, receiver for receiver).
	Noise is out of the specified range.	Check the noise status around this device.
	Internal error	Replace this device.
[Digital error indicator: 1] System error between emitter and receiver	Systems are different between emitter and receiver.	Set the same value to the numbers of emitter and receiver and that of beam channel, and the shield wires.
[Digital error indicator: 2] Series connection error	The serial signal short-circuits or comes down.	Check if the end cap has been fitted properly. Check that the cable for series connection does not short-circuit, or is connected to the correct position (emitter for emitter, receiver for receiver). Check the error contents of the device connected by the cable for series connection.
	Any of the main / sub sensor is in error.	
[Digital error indicator: 3] No. of total units / No. of total beam channels error	No. of total units / No. of total beam channels is out of the specified range.	Set the condition of the series connection within the specification. Refer to “2-5-6 Series Connection.”
[Digital error indicator: 4] Extraneous light error	Extraneous light is entering or light from other model is entering.	When the power is ON, prevent any extraneous light from entering the receiver. If the extraneous light is coming from this device, conduct “2-3-4 Device Placement” or “3-4 Interference Prevention Function.”
[Digital error indicator: 5, 6] Control output (OSSD 1 / 2) error	Control output 1 (OSSD 1) wire (black) and control output 2 (OSSD 2) wire (white) short-circuits with +V or 0V.	Control output 1 (OSSD 1) (black) or control output 2 (OSSD 2) wire (white) control output (OSSD 1 / 2) wires correctly. Refer to “2-5 Wiring.” Current value should be within the specified control output 1 (OSSD 1) (black) or control output 2 (OSSD 2) wire (white). Refer to “6-1 Specifications.”
	Control output 1 (OSSD 1) wire (black) or control output 2 (OSSD 2) wire (white) short-circuit respectively, or short-circuits with other I/O wires.	
	Excessive incoming current flows in the control output 1 (OSSD 1) wire (black) and control output 2 (OSSD 2) wire (white).	
	Output polarity setting wire (shield) and control output 1 (OSSD 1) wire (black) and control output 2 (OSSD 2) wire (white) are not correctly wired.	Wire the output polarity setting wire (shield) correctly. (0V: PNP output, +V: NPN output) Wire the shield wire of the emitter correctly. Refer to “2-5 Wiring.”
	Output circuit error	Output circuit is damaged. Replace this device.
[Digital error indicator: 5] Output polarity setting wire (shield) error	Output polarity setting wire (shield) comes down or short-circuits with other I/O wires. Output polarity setting wire (shield) connection of emitter / receiver is incorrect.	Wire the output polarity setting wire (shield) correctly. (0V: PNP output, +V: NPN output) Wire the output polarity setting wire (shield) of the receiver correctly.

Cause			Remedy
[Digital error indicator: 7] External device error	When using safety relay	Relay contact is welded.	Replace the relay.
		Response time of the relay is slow.	Replace the relay with proper response time. Refer to "3-6 External Device Monitor Function."
		Contacting point "b" of the relay is not wired.	Wire correctly to the relay.
	When setting the external device monitor function to "invalid."	Auxiliary output wire (yellow-green / black) and external device monitor input wire (yellow / black) are not wired.	Connect the auxiliary output wire (yellow-green / black) and the external device monitor input wire (yellow-green).
		Auxiliary output is not correctly operated.	Check if the auxiliary output wire (yellow-green / black) is disconnected or short-circuited.
	Bottom cap cables are adversely connected between emitter and receiver.		Check the connecting locations of the bottom cap cables.
[Digital error indicator: F] Effect from noise / power supply or failure of internal circuit	Affected by noise / power supply. Internal circuit is broken down.		Check the noise status around this device. Check the wiring status, supply voltage, and power supply capacity. When the synchronization + wire (orange) and synchronization - wire (orange / black) is extended with a cable other than exclusive cable, use a 0.2mm <sup>2</sup> or more shielded twisted pair cable. Even if the error is not cleared, contact Panasonic Electric Works SUNX.

#### <Digital error indicator "c" lights up>

Cause	Remedy
Synchronization + wire (orange) or synchronization - wire (orange / black) error. Synchronization + wire (orange) or synchronization - wire (orange / black) comes down or short-circuits.	Connect synchronization + wire (orange) or synchronization - wire (orange / black) properly. Refer to "2-5 Wiring."
Emitter error	Check the operation of the emitter side.

#### <OSSD indicator remains lit in red (light is not received)>

Cause	Remedy
The beam channels are not correctly aligned.	Align the beam channels. Refer to "2-6 Adjustment." Align the top / bottom direction of the beam channel between emitter and receiver.

If the device does not work normally after checking the items above, please consult Panasonic Electric Works SUNX.



# Chapter 6 Specifications / Dimensions

## 6-1 Specifications

### Model

SF4B - □ □ -03<V2>

Number of beam channels

F: Beam pitch 10mm

H: Beam pitch 20mm

Example: SF4B-F55-03<V2>

Beam pitch: 10mm

Number of beam channels: 55 channels

### Model-wise specifications <10mm pitch type>

Type	10mm pitch type					
Item \ Model No.	SF4B-F23-03<V2>	SF4B-F31-03<V2>	SF4B-F39-03<V2>	SF4B-F47-03<V2>	SF4B-F55-03<V2>	SF4B-F63-03<V2>
No. of beam channels	23	31	39	47	55	63
Sensing range	0.3 to 7m					
Beam pitch	10mm					
Protective height	230mm	310mm	390mm	470mm	550mm	630mm
Current consumption	Emitter: 80mA or less, Receiver: 120mA or less			Emitter: 100mA or less, Receiver: 160mA or less		
PFHd	$2.56 \times 10^{-9}$	$2.96 \times 10^{-9}$	$3.36 \times 10^{-9}$	$3.75 \times 10^{-9}$	$4.15 \times 10^{-9}$	$4.55 \times 10^{-9}$
MTTFd	More than 100 years					
Weight (total of emitter and receiver)	Approx. 510g	Approx. 660g	Approx. 810g	Approx. 960g	Approx. 1,110g	Approx. 1,260g

Type	10mm pitch type				
Item \ Model No.	SF4B-F71-03<V2>	SF4B-F79-03<V2>	SF4B-F95-03<V2>	SF4B-F111-03<V2>	SF4B-F127-03<V2>
No. of beam channels	71	79	95	111	127
Sensing range	0.3 to 7m				
Beam pitch	10mm				
Protective height	710mm	790mm	950mm	1,110mm	1,270mm
Current consumption	Emitter: 100mA or less Receiver: 160mA or less		Emitter: 115mA or less Receiver: 190mA or less		Emitter: 135mA or less Receiver: 230mA or less
PFHd	$4.95 \times 10^{-9}$	$5.35 \times 10^{-9}$	$6.15 \times 10^{-9}$	$6.94 \times 10^{-9}$	$7.74 \times 10^{-9}$
MTTFd	More than 100 years				
Weight (total of emitter and receiver)	Approx. 1,420g	Approx. 1,570g	Approx. 1,870g	Approx. 2,170g	Approx. 2,470g

PFHd: Probability of dangerous failure per hour, MTTFd: Mean time to dangerous failure.

# <20mm pitch type>

Type		20mm pitch type					
Item	Model No.	SF4B-H12-03<V2>	SF4B-H16-03<V2>	SF4B-H20-03<V2>	SF4B-H24-03<V2>	SF4B-H28-03<V2>	SF4B-H32-03<V2>
No. of beam channels		12	16	20	24	28	32
Sensing range		0.3 to 9m					
Beam pitch		20mm					
Protective height		230mm	310mm	390mm	470mm	550mm	630mm
Current consumption		Emitter: 70mA or less, Receiver: 95mA or less			Emitter: 80mA or less, Receiver: 115mA or less		
PFHd		2.01×10 <sup>-9</sup>	2.21×10 <sup>-9</sup>	2.41×10 <sup>-9</sup>	2.61×10 <sup>-9</sup>	2.81×10 <sup>-9</sup>	3.01×10 <sup>-9</sup>
MTTFd		More than 100 years					
Weight (total of emitter and receiver)		Approx. 510g	Approx. 660g	Approx. 810g	Approx. 960g	Approx. 1,110g	Approx. 1,260g

Type	20mm pitch type						
Item	Model No..	SF4B-H36-03<V2>	SF4B-H40-03<V2>	SF4B-H48-03<V2>	SF4B-H56-03<V2>	SF4B-H64-03<V2>	SF4B-H72-03<V2>
No. of beam channels		36	40	48	56	64	72
Sensing range		0.3 to 9m					0.3 to 7m
Beam pitch		20mm					
Protective height		710mm	790mm	950mm	1,110mm	1,270mm	1,430mm
Current consumption		Emitter: 80mA or less Receiver: 115mA or less	Emitter: 90mA or less Receiver: 140mA or less		Emitter: 100mA or less Receiver: 160mA or less		Emitter: 110mA or less Receiver: 180mA or less
PFHd		3.21×10 <sup>-9</sup>	3.41×10 <sup>-9</sup>	3.80×10 <sup>-9</sup>	4.20×10 <sup>-9</sup>	4.60×10 <sup>-9</sup>	5.00×10 <sup>-9</sup>
MTTFd		More than 100 years					
Weight (total of emitter and receiver)		Approx. 1,420g	Approx. 1,570g	Approx. 1,870g	Approx. 2,170g	Approx. 2,470g	Approx. 2,770g

Type		20mm pitch type	
Item	Model No.	SF4B-H80-03<V2>	SF4B-H96-03<V2>
No. of beam channels		80	96
Sensing range		0.3 to 7m	
Beam pitch		20mm	
Protective height		1,590mm	1,750mm
Current consumption		Emitter: 110mA or less Receiver: 180mA or less	Emitter: 120mA or less Receiver: 200mA or less
PFHd		$5.40 \times 10^{-9}$	$6.20 \times 10^{-9}$
MTTFd		More than 100 years	
Weight (total of emitter and receiver)		Approx. 3,070g	Approx. 3,370g

PFHd: Probability of dangerous failure per hour, MTTFd: Mean time to dangerous failure.

## Common specifications

Type	10mm pitch type	20mm pitch type
Item \ Model No.	SF4B-F□-03<V2>	SF4B-H□-03<V2>
Detecting capability (Min. sensing object)	ø14mm opaque object	ø25mm opaque object
Effective aperture angle (EAA)	±2.5 degree or less [for sensing range exceeding 3m (Required by IEC 61496-2, ANSI/UL 61496-2)]	
Supply voltage	24V DC±10% Ripple P-P10% or less	
Control output (OSSD 1 / 2)	PNP open-collector / NPN open-collector transistor (switching type)	
	<b>&lt;For PNP output&gt;</b> <ul style="list-style-type: none"> <li>Maximum source current: 200mA</li> <li>Applied voltage: Same as supply voltage (between the control output and +V)</li> <li>Residual voltage: 2.5V or less (source current 200mA, when using 20m length cable)</li> <li>Leakage current: 0.1mA or less (Including power supply OFF condition)</li> <li>Maximum load capacity: 0.22μF (No load to maximum output current)</li> <li>Load wiring resistance: 3Ω or less</li> </ul>	<b>&lt;For NPN output&gt;</b> <ul style="list-style-type: none"> <li>Maximum sink current: 200mA</li> <li>Applied voltage: Same as supply voltage (between the control output and 0V)</li> <li>Residual voltage: 2.5V or less (sink current 200mA, when using 20m length cable)</li> <li>Leakage current: 0.1mA or less (Including power supply OFF condition)</li> <li>Maximum load capacity: 0.22μF (No load to maximum output current)</li> <li>Load wiring resistance: 3Ω or less</li> </ul>
	ON when all beams are received, OFF when one or more beams are interrupted (OFF when fault occurs in the sensor to the synchronization single error, too)	
	Incorporated	
Response time	In normal operation...OFF response: 14ms or less, ON response: 80 to 90ms	
Auxiliary output (Non-safety output)	PNP open-collector transistor / NPN open-collector transistor (switching type)	
	<b>&lt;For PNP output&gt;</b> <ul style="list-style-type: none"> <li>Maximum source current: 60mA</li> <li>Applied voltage: Same as supply voltage (between the auxiliary output and +V)</li> <li>Residual voltage: 2.5V or less (source current 60mA, when using 20m length cable)</li> </ul>	<b>&lt;For NPN output&gt;</b> <ul style="list-style-type: none"> <li>Maximum sink current: 60mA</li> <li>Applied voltage: Same as supply voltage (between the auxiliary output and 0V)</li> <li>Residual voltage: 2.5V or less (sink current 60mA, when using 20m length cable)</li> </ul>
	When OSSDs are ON: OFF, when OSSDs are OFF: ON	
	Incorporated	
Protection	IP65 and IP67(IEC)	
Ambient temperature	-10 to +55°C(No dew condensation or icing allowed), Storage:-25 to +70°C	
Ambient humidity	30 to 85%RH, Storage: 30 to 95%RH	
Ambient illuminance	Incandescent lamp: 3,500lx or less at the light-receiving surface	
Voltage withstandability	1,000V AC for one min. (between all supply terminals connected together and enclosure)	
Insulation resistance	20MΩ or more with 500V DC mega (between all supply terminals connected together and enclosure)	
Vibration resistance	10 to 55Hz frequency, 0.75mm amplitude in X, Y, and Z directions for two hours each	
Shock resistance	300m/s <sup>2</sup> acceleration (Approx. 30G) in X, Y and Z directions for three times each	
Emitting element	Infrared LED (Peak emission wavelength: 870nm)	
Connection method	Connection with connectors	
Cable extension	Extension up to total 50m is possible for both emitter and receiver connecting cable (optional) (Note 1)	
Material	Enclosure: Aluminum, Upper / lower case: Aluminum, Sensing surface: PC / Polyester resin, Cap: PBT	
Accessory	<b>MS-SFB-2</b> (Intermediate supporting bracket): (Note 2) <b>SF4B-TR14</b> (Test rod): 1 pc.	<b>MS-SFB-2</b> (Intermediate supporting bracket): (Note 2) <b>SF4B-TR25</b> (Test rod): 1 pc.
Applicable standard	EN 61496-1 (Type 4), EN 55011, EN ISO 13849-1 (Category 4, PL <sub>e</sub> ), IEC 61496-1/2 (Type 4) ISO 13849-1 (Category 4, PL <sub>e</sub> ), IEC 61508-1 to 7 (SIL3), JIS B 9704-1/2 (Type 4) JIS B 9705-1 (Category 4), JIS C 0508 (SIL3), ANSI/UL 61496-1/2 (Type 4), UL 1998 (Class 2)	

Notes: 1) The cable can be extended within 30m (for emitter / receiver) when two devices are connected in series connection, within 20m when three devices are connected in series connection.

2) The intermediate supporting bracket (**MS-SFB-2**) is enclosed with the following devices. The quantity of the enclosed bracket differs depending on the device as follows:

1 set: **SF4B-F□-03<V2>**...79 to 111 beam channels

**SF4B-H□-03<V2>**...40 to 56 beam channels

2 sets: **SF4B-F127-03<V2>**, **SF4B-H□-03<V2>**...64 to 80 beam channels


3 sets: **SF4B-H□-03<V2>**...88 to 96 beam channels



Both emitter and receiver are adjusted before shipment, please apply both emitter and receiver with the same serial No. The serial No. is indicated on the plates of both emitter and receiver. (Under the model represents the serial No.)

## 6-2 Options

- Front protection cover: 1 pc.




Model No.	Applicable beam channel No.		Remarks
FC-SFBH-12	SF4B-F23-03<V2>	SF4B-H12-03<V2>	Protects the sensing surface of the device from dirt, etc.
FC-SFBH-16	SF4B-F31-03<V2>	SF4B-H16-03<V2>	
FC-SFBH-20	SF4B-F39-03<V2>	SF4B-H20-03<V2>	
FC-SFBH-24	SF4B-F47-03<V2>	SF4B-H24-03<V2>	
FC-SFBH-28	SF4B-F55-03<V2>	SF4B-H28-03<V2>	
FC-SFBH-32	SF4B-F63-03<V2>	SF4B-H32-03<V2>	
FC-SFBH-36	SF4B-F71-03<V2>	SF4B-H36-03<V2>	
FC-SFBH-40	SF4B-F79-03<V2>	SF4B-H40-03<V2>	
FC-SFBH-48	SF4B-F95-03<V2>	SF4B-H48-03<V2>	
FC-SFBH-56	SF4B-F111-03<V2>	SF4B-H56-03<V2>	
FC-SFBH-64	SF4B-F127-03<V2>	SF4B-H64-03<V2>	
FC-SFBH-72	—	SF4B-H72-03<V2>	
FC-SFBH-80	—	SF4B-H80-03<V2>	
FC-SFBH-88	—	SF4B-H88-03<V2>	
FC-SFBH-96	—	SF4B-H96-03<V2>	


When the front protection cover is fitted, the sensing distance is shortened.

- 8-core bottom cap cable: 2 pcs./set

<Discrete wire>




<Connector>



Type	Model No.	Cable length	Remarks
Discrete wire	SFB-CCB3	3m	This cable is used for normal operation. For emitter: Gray connector, 8-core shielded cable For receiver: Black connector, 8-core shielded cable
	SFB-CCB7	7m	
	SFB-CCB10	10m	
	SFB-CCB15	15m	
Connector	SFB-CB05	0.5m	
	SFB-CB5	5m	
	SFB-CB10	10m	

- 8-core extension cable with connector on one end: 2 pcs./set



Type	Model No.	Cable length	Remarks
Discrete wire	SFB-CC3	3m	This cable is used for extending the normal cable. For emitter: Gray connector, 8-core shielded cable For receiver: Black connector, 8-core shielded cable
	SFB-CC10	10m	

- M8 rear mounting bracket: 4 pcs./set



Model No.	Remarks
<b>MS-SFB-7-T</b>	This mounting bracket allows the device to be mounted at the rear. For one hexagon-socket head bolt [M8].

- M8 side mounting bracket: 4 pcs./set  
[L type: 2 pcs., R type: 2pcs.]

<L type>

<R type>




Model No.	Remarks
<b>MS-SFB-8-T</b>	This mounting bracket allows the device to be mounted at the side. For one hexagon-socket head bolt [M8].

- M8 rear / side mounting bracket set: 1 set

[For rear mounting: 4 pcs., for side mounting: 4 pcs. (L type: 2 pcs., R type: 2pcs.)]

<For rear mounting> <For side mounting>




<L type>

<R type>




Model No.	Remarks
<b>MS-SFB-1-T2</b>	This mounting bracket allows the device to be mounted at the rear or the side by changing the parts. For one hexagon-socket head bolt [M8].

- M5/M8 360°-rotatable mounting bracket : 4 pcs./set




Model No.	Remarks
<b>MS-SFB-1</b>	This mounting bracket enables easy beam alignment. For two hexagon-socket head bolts [M5] or one hexagon-socket head bolt [M8].

- M5 pitch adapter bracket: 4 pcs./set




Model No.	Remarks
-----------	---------

- M8 360°-rotatable mounting bracket : 4 pcs./set




Model No.	Remarks
<b>MS-SFB-1-T</b>	This mounting bracket enables easy beam alignment. For one hexagon-socket head bolt [M8].

- M8 pitch adapter bracket : 4 pcs./set



Model No.	Remarks
<b>MS-SFB-4-T</b>	This mounting bracket is for replacing the other Panasonic Electric Works SUNX light curtains (sensing height 200mm or more) by <b>SF4B&lt;V2&gt;</b> series. For one hexagon-socket head bolt [M8].

● 8-core extension cable with connectors on both ends: 1 pc.




Type	Model No.	Cable length	Remarks
For emitter	SFB-CCJ10E	10m	This cable is used for extending the normal cable. The connector is attached on both ends of the cable. For emitter: Gray connector, 8-core shielded cable For receiver: Black connector, 8-core shielded cable
For receiver	SFB-CCJ10D		

● Cable for series connection: 2 pcs./set




Model No.	Cable length	Remarks
SFB-CSL01	0.1m	This cable is used for connecting the devices in series. Common for emitter and receiver.
SFB-CSL05	0.5m	
SFB-CSL1	1m	
SFB-CSL5	5m	

- Dead zoneless mounting bracket: 4 pcs./set




Model No.	Remarks
<b>MS-SFB-3</b>	This is the mounting bracket for reducing the dead space.

- Laser alignment tool for light curtain: 1 pc.




Model No.	Remarks
<b>SF-LAT-2N</b>	Convenient for aligning the beam channels.

- Connector connection type control unit: 1 pc.




Model No.	Remarks
<b>SF-C11</b>	This is the control unit conforming to European / North American safety standards. Applicable to 8-core cable with connector.

- Thin type control unit: 1 pc.



Model No.	Remarks
<b>SF-C13</b>	This is the controller conforming to European / North American safety standards.

● Protection bar set: 1 set



Model No.	Applicable model		Remarks
MC-SFBH-12-T, MC-SFBH-12	SF4B-F23-03<V2>	SF4B-H12-03<V2>	This unit protects the lens surface of the light curtain from being hit and damaged by work pieces.
MC-SFBH-16-T, MC-SFBH-16	SF4B-F31-03<V2>	SF4B-H16-03<V2>	
MC-SFBH-20-T, MC-SFBH-20	SF4B-F39-03<V2>	SF4B-H20-03<V2>	
MC-SFBH-24-T, MC-SFBH-24	SF4B-F47-03<V2>	SF4B-H24-03<V2>	
MC-SFBH-28-T, MC-SFBH-28	SF4B-F55-03<V2>	SF4B-H28-03<V2>	
MC-SFBH-32-T, MC-SFBH-32	SF4B-F63-03<V2>	SF4B-H32-03<V2>	
MC-SFBH-36-T, MC-SFBH-36	SF4B-F71-03<V2>	SF4B-H36-03<V2>	
MC-SFBH-44-T, MC-SFBH-44	SF4B-F79-03<V2>	SF4B-H40-03<V2>	
MC-SFBH-48-T, MC-SFBH-48	SF4B-F95-03<V2>	SF4B-H48-03<V2>	
MC-SFBH-56-T, MC-SFBH-56	SF4B-F111-03<V2>	SF4B-H56-03<V2>	
MC-SFBH-64-T, MC-SFBH-64	SF4B-F127-03<V2>	SF4B-H64-03<V2>	
MC-SFBH-72-T, MC-SFBH-72	—	SF4B-H72-03<V2>	
MC-SFBH-80-T, MC-SFBH-80	—	SF4B-H80-03<V2>	
MC-SFBH-88-T, MC-SFBH-88	—	SF4B-H88-03<V2>	
MC-SFBH-96-T, MC-SFBH-96	—	SF4B-H96-03<V2>	


Note: The protection bar intermediate supporting bracket (optional) is for the protection bar longer than MC-SFBH-48-T and MC-SFBH-48 in length. Use the bracket when the protection bar bends a lot.



## 6-3 Dimensions

### 6-3-1 When Using M8 Rear Mounting Bracket (MS-SFB-7-T)

(Unit: mm)




Model No.		A	B	C	D	E	F
SF4B-F23-03<V2>	SF4B-H12-03<V2>	230	279	296	—	—	—
SF4B-F31-03<V2>	SF4B-H16-03<V2>	310	359	376	—	—	—
SF4B-F39-03<V2>	SF4B-H20-03<V2>	390	439	456	—	—	—
SF4B-F47-03<V2>	SF4B-H24-03<V2>	470	519	536	—	—	—
SF4B-F55-03<V2>	SF4B-H28-03<V2>	550	599	616	—	—	—
SF4B-F63-03<V2>	SF4B-H32-03<V2>	630	679	696	—	—	—
SF4B-F71-03<V2>	SF4B-H36-03<V2>	710	759	776	—	—	—
SF4B-F79-03<V2>	SF4B-H40-03<V2>	790	839	856	395	—	—
SF4B-F95-03<V2>	SF4B-H48-03<V2>	950	999	1,016	475	—	—
SF4B-F111-03<V2>	SF4B-H56<-03V2>	1,110	1,159	1,176	555	—	—
SF4B-F127-03<V2>	SF4B-H64-03<V2>	1,270	1,319	1,336	423	847	—
—	SF4B-H72-03<V2>	1,430	1,479	1,496	477	953	—
—	SF4B-H80-03<V2>	1,590	1,639	1,656	530	1,060	—
—	SF4B-H88-03<V2>	1,750	1,799	1,816	438	875	1,313
—	SF4B-H96-03<V2>	1,910	1,959	1,946	478	955	1,433

Type	G	H
SF4B-F□-03<V2>	10	5
SF4B-H□-03<V2>	20	5

Note: The intermediate supporting bracket (**MS-SFB-2**) is enclosed with the devices.  
The number of the brackets varies depending on the device.

## 6-3-2 When Using M8 Side Mounting Bracket (MS-SFB-8-T)

(Unit: mm)



<Emitter>

<Receiver>


Model No.		A	B	C	D	E	F
SF4B-F23-03<V2>	SF4B-H12-03<V2>	230	279	296	—	—	—
SF4B-F31-03<V2>	SF4B-H16-03<V2>	310	359	376	—	—	—
SF4B-F39-03<V2>	SF4B-H20-03<V2>	390	439	456	—	—	—
SF4B-F47-03<V2>	SF4B-H24-03<V2>	470	519	536	—	—	—
SF4B-F55-03<V2>	SF4B-H28-03<V2>	550	599	616	—	—	—
SF4B-F63-03<V2>	SF4B-H32-03<V2>	630	679	696	—	—	—
SF4B-F71-03<V2>	SF4B-H36-03<V2>	710	759	776	—	—	—
SF4B-F79-03<V2>	SF4B-H40-03<V2>	790	839	856	395	—	—
SF4B-F95-03<V2>	SF4B-H48-03<V2>	950	999	1,016	475	—	—
SF4B-F111-03<V2>	SF4B-H56-03<V2>	1,110	1,159	1,176	555	—	—
SF4B-F127-03<V2>	SF4B-H64-03<V2>	1,270	1,319	1,336	423	847	—
—	SF4B-H72-03<V2>	1,430	1,479	1,496	477	953	—
—	SF4B-H80-03<V2>	1,590	1,639	1,656	530	1,060	—
—	SF4B-H88-03<V2>	1,750	1,799	1,816	438	875	1,313
—	SF4B-H96-03<V2>	1,910	1,959	1,946	478	955	1,433

Type	G	H
SF4B-F□-03<V2>	10	5
SF4B-H□-03<V2>	20	5

Note: The intermediate supporting bracket (**MS-SFB-2**) is enclosed with the devices.  
The number of the brackets varies depending on the device.

### 6-3-3 Rear Mounting with Dead Zoneless Mounting Bracket (MS-SFB-3)

(Unit: mm)




Model No.		A	J	K	L	M	N
SF4B-F23-03<V2>	SF4B-H12-03<V2>	230	209	201	—	—	—
SF4B-F31-03<V2>	SF4B-H16-03<V2>	310	289	281	—	—	—
SF4B-F39-03<V2>	SF4B-H20-03<V2>	390	369	361	—	—	—
SF4B-F47-03<V2>	SF4B-H24-03<V2>	470	449	441	—	—	—
SF4B-F55-03<V2>	SF4B-H28-03<V2>	550	529	521	—	—	—
SF4B-F63-03<V2>	SF4B-H32-03<V2>	630	609	601	—	—	—
SF4B-F71-03<V2>	SF4B-H36-03<V2>	710	689	681	—	—	—
SF4B-F79-03<V2>	SF4B-H40-03<V2>	790	769	761	370	—	—
SF4B-F95-03<V2>	SF4B-H48-03<V2>	950	929	921	450	—	—
SF4B-F111-03<V2>	SF4B-H56-03<V2>	1,110	1,089	1,081	530	—	—
SF4B-F127-03<V2>	SF4B-H64-03<V2>	1,270	1,249	1,241	398	822	—
—	SF4B-H72-03<V2>	1,430	1,409	1,401	452	928	—
—	SF4B-H80-03<V2>	1,590	1,569	1,561	505	1,035	—
—	SF4B-H88-03<V2>	1,750	1,729	1,721	413	850	1,288
—	SF4B-H96-03<V2>	1,910	1,889	1,881	453	930	1,408

Type	G	H
SF4B-F□-03<V2>	10	5
SF4B-H□-03<V2>	20	5

Note: The intermediate supporting bracket (MS-SFB-2) is enclosed with the devices.  
The number of the brackets varies depending on the device.

### 6-3-4 Side Mounting with Dead Zoneless Mounting Bracket (MS-SFB-3)

(Unit: mm)



**<Emitter>**

**<Receiver>**

Model No.		A	J	K	L	M	N
SF4B-F23-03<V2>	SF4B-H12-03<V2>	230	209	201	—	—	—
SF4B-F31-03<V2>	SF4B-H16-03<V2>	310	289	281	—	—	—
SF4B-F39-03<V2>	SF4B-H20-03<V2>	390	369	361	—	—	—
SF4B-F47-03<V2>	SF4B-H24-03<V2>	470	449	441	—	—	—
SF4B-F55-03<V2>	SF4B-H28-03<V2>	550	529	521	—	—	—
SF4B-F63-03<V2>	SF4B-H32-03<V2>	630	609	601	—	—	—
SF4B-F71-03<V2>	SF4B-H36-03<V2>	710	689	681	—	—	—
SF4B-F79-03<V2>	SF4B-H40-03<V2>	790	769	761	370	—	—
SF4B-F95-03<V2>	SF4B-H48-03<V2>	950	929	921	450	—	—
SF4B-F111-03<V2>	SF4B-H56-03<V2>	1,110	1,089	1,081	530	—	—
SF4B-F127-03<V2>	SF4B-H64-03<V2>	1,270	1,249	1,241	398	822	—
	SF4B-H72-03<V2>	1,430	1,409	1,401	452	928	—
	SF4B-H80-03<V2>	1,590	1,569	1,561	505	1,035	—
	SF4B-H88-03<V2>	1,750	1,729	1,721	413	850	1,288
	SF4B-H96-03<V2>	1,910	1,889	1,881	453	930	1,408

Type	G	H
SF4B-F□-03<V2>	10	5
SF4B-H□-03<V2>	20	5


Note: The intermediate supporting bracket (**MS-SFB-2**) is enclosed with the devices.  
The number of the brackets varies depending on the device.

## 6-3-5 Mounting Brackets

(Unit: mm)

### 1) M8 rear mounting bracket: MS-SFB-7-T


M8 rear / side mounting bracket set: MS-SFB-1-T2 (for rear mounting)



Material: Cold rolled carbon steel (trivalent chromate coating)

### 2) M8 side mounting bracket: MS-SFB-8-T (L)


M8 rear / side mounting bracket set: MS-SFB-1-T2 (L) (for side mounting)



Material: Cold rolled carbon steel (trivalent chromate coating)


### 3) M8 side mounting bracket: MS-SFB-8-T (R)

M8 rear / side mounting bracket set: MS-SFB-1-T2 (R) (for side mounting)




Material: Cold rolled carbon steel (trivalent chromate coating)

#### 4) M5 / M8 360°-rotatable mounting bracket: MS-SFB-1




Material: Die-cast zinc alloy

#### 5) M8 360°-rotatable mounting bracket: MS-SFB-1-T




Material: Die-cast zinc alloy

## 6) M5 pitch adapter bracket: MS-SFB-4




Material: Die-cast zinc alloy

## 7) M8 pitch adapter bracket: MS-SFB-4-T




Material: Die-cast zinc alloy

## 8) Intermediate supporting bracket / MS-SFB-2



Material: Die-cast zinc alloy

## 9) Dead zoneless mounting bracket / MS-SFB-3



Material: Die-cast zinc alloy



## Chapter 7 Others

### 7-1 Glossary

Machinery Directive	This directive is for an assembly of linked parts or components, energized by an electricity, compressed air or oil pressure, etc. and at least one of which moves, and a component which fulfills a safety function and is released into the market by itself.
EMC Directive	The directives is to any electric or electronic devices which will create more than a limited amount of RF interference, or will withstand a certain amount of Electro Magnetic fields while operating as intended within specifications.
EN 61496-1 IEC 61496-1/2 ANSI/UL 61496-1/2 JIS B 9704-1/2	The standards that pertain to machine safety, especially electro-sensitive protective equipment (ESPE). EN 61496-1, IEC 61496-1, ANSI/UL 61496-1 or JIS B 9704-1 gives general rules or failure mode and effect analysis, EMC requirements, etc. IEC 61496-2, ANSI/UL 61496-2 or JIS B 9704-2 specifies effective aperture angle, protection against extraneous light sources, etc, for Active Opto-electronic Protective Devices (AOPDs).
EN 55011	Specifies the limits and methods of measurement of radio disturbance characteristics of industrial, scientific and medical (ISM) radio-frequency equipment.
EN ISO 13849-1 ISO 13849-1 JIS B 9705-1	The standard that specifies the safety-related matters of machine safety / control system. They give roles for level (category) of structure and fault detection reliability, and for level of safety future performance capability (PL: Performance Level).
UL 1998	UL standard for safety-related software in programmable components.
ESPE	The abbreviation for Electro-Sensitive Protective Equipment.
Control output (OSSD)	The abbreviation for Output Signal Switching Device. A component of the light curtain that turns OFF when light of the light curtain is blocked.
FSD	The abbreviation for Final Switching Device. The component of the machine's safety related control system that open-circuits the MPCE circuit when the OSSD operates due to the light from the light curtain being blocked.
Test rod	This is a rod for checking the detection capability of this device. It has dimensions corresponding to the minimum sensing object for this device.
Main sensor / Sub sensor	For series connection, the sensor to which the power supply or the output is connected is called main sensor, and the others are called sub sensor.
Lockout	It is one of the safe status of this device. Operation is stopped if the self-diagnosis function determines that an irrecoverable failure (OSSDs do not operate normally, etc.) has occurred. If an emitter is in lockout condition, it will stop emitting light. If a receiver is in lockout condition, OSSDs are turned OFF.
Safety distance	It is the minimum distance that must be maintained between the light curtain and the dangerous parts of a machine so that the machine can be stopped before a human body or an object can reach the dangerous parts.
Sensing height (Protective height)	The length of the beam-axis direction that the min. sensing object can be detected. The length from the center of the first beam channel to the center of the last beam channel in addition to +10mm (+5mm upward, +5mm downward).

Sensing range	It is the range between the facing emitter and receiver.
Sensing area	It is the area over which intrusion by people or objects can be detected by one set of the device. It is given by multiplying the sensing height (protective height) by the sensing range.
Emission halt function	This function enables checking of the receiver operation by turning OFF light emission. It is possible to halt emission by keeping the terminal open, and to have normal emission by connecting it to 0V (+V for NPN output).
PSDI	The abbreviation for the Presence Sensing Device Initiation. The safety device that restarts automatically without any operation by the operator after the device detects danger status and halts for a while.

## 7-2 CE Marking Declaration of Conformity

### **Itemized Essentials of EC Declaration of Conformity**

**Manufacturer's Name:** Panasonic Electric Works SUNX Co., Ltd.

**Manufacturer's Address:** 2431-1, Ushiyama-cho, Kasugai, Aichi 486-0901, Japan

**EC Representative's Name:** Panasonic Electric Works Europe AG

**EC Representative's Address:** Rudolf-Diesel-Ring 2, 83607 Holzkirchen, Germany

**Product:** Active Opto-electronic Protective Device (Light Curtain)

**Model Name:** SF4B Series

**Trade Name:** Panasonic

**Application of Council Directive:**

- 2006/42/EC Machinery Directive
- 2004/108/EC EMC Directive

**Tested according to:**

- EN 61496-1: 2004
- IEC 61496-2: 2006
- IEC 61508-1: 1998
- IEC 61508-2: 2000
- IEC 61508-3: 1998
- IEC 61508-4: 1998
- EN ISO 13849-1: 2008
- EN 50178: 1997
- EN 55011: 2007 +A2: 2007
- EN 61000-6-2: 2005

**Type Examination:** Certified by TÜV SÜD Product Service GmbH Ridlerstrasse  
65 80339 München Germany

## **Revision History**

First edition: July 21, 2009

Second edition: October 1, 2010

## **1. WARRANTIES:**

- (1) Subject to the exclusions stated in 2 (EXCLUSIONS) herein below, Panasonic Electric Works SUNX warrants the Products to be free of defects in material and workmanship for a period of one (1) year from the date of shipment under normal usage in environments commonly found in manufacturing industry.
- (2) Any Products found to be defective must be shipped to Panasonic Electric Works SUNX with all shipping costs paid by Purchaser or offered to Panasonic Electric Works SUNX for inspection and examination. Upon examination by Panasonic Electric Works SUNX, Panasonic Electric Works SUNX will, at its sole discretion, repair or replace at no charge, or refund the purchase price of, any Products found to be defective.

## **2. EXCLUSIONS:**

- (1) This warranty does not apply to defects resulting from any cause:
  - (i) which was due to abuse, misuse, mishandling, improper installation, improper interfacing, or improper repair by Purchaser;
  - (ii) which was due to unauthorized modification by Purchaser, in part or in whole, whether in structure, performance or specification;
  - (iii) which was not discoverable by a person with the state-of-the-art scientific and technical knowledge at the time of manufacture;
  - (iv) which was due to an operation or use by Purchaser outside of the limits of operation or environment specified by Panasonic Electric Works SUNX;
  - (v) which was due to normal wear and tear;
  - (vi) which was due to Force Majeure; and
  - (vii) which was due to any use or application expressly discouraged by Panasonic Electric Works SUNX in 4 (CAUTIONS FOR SAFE USE) hereunder.
- (2) This warranty extends only to the first purchaser for application, and is not transferable to any person or entity which purchased from such purchaser for application.

## **3. DISCLAIMERS**

- (1) Panasonic Electric Works SUNX's sole obligation and liability under this warranty is limited to the repair or replacement, or refund of the purchase price, of a defective Product, at Panasonic Electric Works SUNX's option.
- (2) THE REPAIR, REPLACEMENT, OR REFUND IS THE EXCLUSIVE REMEDY OF THE PURCHASER, AND ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF PROPRIETARY RIGHTS, ARE HEREBY EXPRESSLY DISCLAIMED. IN NO EVENT SHALL PANASONIC ELECTRIC WORKS SUNX AND ITS AFFILIATED ENTITIES BE LIABLE FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCTS, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, GENERAL TERMS AND CONDITIONS 4 OR ANY DAMAGES RESULTING FROM LOSS OF USE, BUSINESS INTERRUPTION, LOSS OF INFORMATION, LOSS OR INACCURACY OF DATA, LOSS OF PROFITS, LOSS OF SAVINGS, THE COST OF PROCUREMENT OF SUBSTITUTED GOODS, SERVICES OR TECHNOLOGIES, OR FOR ANY MATTER ARISING OUT OF OR IN CONNECTION WITH THE USE OR INABILITY TO USE THE PRODUCTS.

## **4. CAUTIONS FOR SAFE USE**

- (1) The applications shown in the catalogue are only suggestions, and it is Purchaser's sole responsibility to ascertain the fitness and suitability of the Products for any particular application, as well as to abide by Purchaser's applicable local laws and regulations, if any.
- (2) Never use the Products NOT rated or designated as "SAFETY SENSOR" in any application involving risk to life or property. When such a use is made by Purchaser, such Purchaser shall indemnify and hold harmless Panasonic Electric Works SUNX from any liability or damage whatsoever arising out of or in relation to such use.
- (3) In incorporating the Products to any equipment, facilities or systems, it is highly recommended to employ fail-safe designs, including but not limited to a redundant +++design, flame propagation prevention design, and malfunction prevention design so as not to cause any risk of bodily injury, fire accident, or social damage due to any failure of such equipment, facilities or systems.
- (4) The Products are each intended for use only in environments commonly found in manufacturing industry, and, unless expressly allowed in the catalogue, specification or otherwise, shall not be used in, or incorporated into, any equipment, facilities or systems, such as those:
  - (a) which are used for the protection of human life or body parts;
  - (b) which are used outdoors or in environments subject to any likelihood of chemical contamination or electromagnetic influence;
  - (c) which are likely to be used beyond the limits of operations or environments specified by Panasonic Electric Works SUNX in the catalogue or otherwise;
  - (d) which may cause risk to life or property, such as nuclear energy control equipment, transportation equipment (whether on rail or land, or in air or at sea), and medical equipment;
  - (e) which are operated continuously each day for 24 hours; and
  - (f) which otherwise require a high level of safety performance similar to that required in those equipment, facilities or systems as listed in (a) through (e) above.

## **5. EXPORT CONTROL LAWS**

In some jurisdictions, the Products may be subject to local export laws and regulations. If any diversion or re-export is to be made, Purchaser is advised to abide by such local export laws and regulations, if any, at its own responsibility.

## Panasonic Electric Works SUNX Co., Ltd.

<http://panasonic-electric-works.net/sunx>

**Overseas Sales Division (Head Office)**

2431-1 Ushiyama-cho, Kasugai-shi, Aichi, 486-0901, Japan

Phone: +81-568-33-7861 FAX: +81-568-33-8591

**Europe Headquarter: Panasonic Electric Works Europe AG**

Rudolf-Diesel-Ring 2, D-83607 Holzkirchen, Germany

Phone: +49-8024-648-0

**US Headquarter: Panasonic Electric Works Corporation of America**

629 Central Avenue New Providence, New Jersey 07974 USA

Phone: +1-908-464-3550

MJE-SF4B03V2 No.0016-54V PRINTED IN JAPAN © Panasonic Electric Works SUNX Co., Ltd. 2010